


# COIN SWITCH ADJUSTMENT

SHARP BLOW ON FRONT DOOR  
WILL MOVE DAMPER AWAY FROM  
THIS SURFACE. FORMED ARM OF  
DAMPER STRIKES UPPER SWITCH  
BLADE KEEPING POINTS FROM  
MAKING CONTACT.

2 BEND BACKING BLADE TO  
ESTABLISH PROPER POINT  
GAP.

.018" FOR 10¢ COIN  
.032" FOR 5¢ COIN  
.047" FOR 25¢ COIN

3 ADJUST THIS BLADE TO REST  
AGAINST BACKING BLADE WITH  
VERY LIGHT PRESSURE.  
2 GRAMS MAXIMUM AT END OF  
BLADE.



1 ADJUST THIS BLADE AGAINST  
WIRE FORM AS TIGHT AS  
POSSIBLE WITHOUT RETARDING  
PASSAGE OF COIN.  
RECOMMEND:  
5 TO 6 GRAMS FOR 10¢ COIN.  
10 GRAMS FOR 5¢ COIN.  
12 GRAMS FOR 25¢ COIN.