

PARTS LIST

BALL KICKERS
 O = USED IN OUTHOLE R = RIGHT
 P = USED ON PLAYBOARD L = LEFT

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
JUNGLE LIFE 1-73	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS CREDIT BONUS	A-11669 A-11654 A-14753 A-11650	B-14418 B-14101 C-12493 C-12493 B-14904	B-9998 B-14921 B-9166 B-9166 B-14905
PRO FOOTBALL 2-73	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ONES POINTS TENS POINTS VARI-TARGET ADVANCE RELAY	A-10547 A-9012 A-11669 A-9013	A-9016 A-9017 B-14254 C-12493 C-12493 C-12493 C-12493 C-12493 A-13894 A-9016	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 B-9166 B-9166 B-9015
JACK IN THE BOX 5-73	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS SCORING	A-10547 A-9012 A-12399 A-10276	A-9016 A-9017 C-12567 C-12493 C-12493 C-12493 B-15180	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-14521
TOP HAND 5-73	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS CREDIT BONUS	A-11669 A-14753 A-10276	B-14418 B-14101 C-12493 B-14858	B-9998 B-14921 B-9166 B-12757
JUNGLE KING 5-73	BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-11650 A-11650	B-14566 C-12493 C-12493 B-14904	B-7618 B-9166 B-9166 B-14905
JUMPING JACK 8-73	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS SCORING	A-9012 A-12399 A-10276	A-9016 A-9017 B-12569 C-12493 C-12493 C-12493 B-15180	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 B-14521
HIGH HAND 8-73	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-10547 A-9012 A-11669 A-10276	A-9016 A-9017 B-15004 C-12493 C-12493 C-12493 B-14779	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 B-12757
TEN UP 8-73	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS CREDIT WOW CONTROL RELAY	A-11669 A-11654 A-14753 A-9012	B-14418 B-14101 C-12493 A-9016	B-9998 B-14921 B-9166 B-9015

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-14513 (P) A-10945 (O)	A-14834	C-14385 P A-8215 M	A-8678
A-14834 (O)	A-14834	C-14266 P	A-7907
A-10108 (P) A-10945 (O)		C-14483 P A-8215 M	A-7766
A-10108 (P) A-10945 (O)	A-14834	C-14751 P A-8215 M	A-7907
A-14513 (P) A-10945 (O)	A-14834	C-14385 P A-8215 M	A-8678
A-10108 (P) A-10945 (O)		C-14483 P A-8215 M	A-7766
A-10108 (P) A-10945 (O)	A-14834	C-14751 P A-8215 M	A-7766
A-10108 (P) A-10945 (O)	A-14834	C-14844 P A-8215 M	A-8678

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
HOT SHOT 12-73	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-10547 A-9012 A-12399 A-10276	A-9016 A-9017 C-14578 C-12493 C-12493 C-12493 B-14575	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-14577
KING PIN 12-73	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS SPOT CONTROL RELAY	A-10547 A-9012 A-11669 D-8755	A-9016 A-9017 B-14254 C-12493 C-12493 C-12493 A-9016 A-9017	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 B-9015 B-9015
PRO POOL 12-73	BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS	A-11650	B-14566 C-12493	B-7618 B-9166

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-10108 (P) A-10945 (O)	A-14833 A-14834	C-14607 P A-8215 M	A-7907
A-10108 (P) A-10945 (O)	A-14834	C-14844 P A-8215 M	A-7907
A-10108 (P) A-10945 (O)	A-14833 A-14834	C-14607 P A-8215 M	A-7907

NOTES

PARTS LIST

BALL KICKERS
 O = USED IN OUTHOLE R = RIGHT
 P = USED ON PLAYBOARD L = LEFT

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
BIG SHOT 1-74	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-10547 A-9012 A-12399 A-10276	A-9016 A-9017 B-14654 C-12493 C-12493 C-12493 B-14575	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 B-14577
SKY DIVE 2-74	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS	A-11669 A-11654 	B-14418 C-14101 C-12493 C-12493	B-9998 B-14920 B-9166 B-9166
BIG INDIAN 4-74	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS VARI-TARGET	A-10547 D-8755 A-12399 A-13606	A-9016 A-9017 C-12567 C-12493 C-12493 C-12493 B-13020 A-14927	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-13019
SKY JUMP 4-74	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS MULTIPLIER CONTROL	A-10547 D-8755 A-11669 A-10276	A-9016 A-9017 B-15004 C-12493 C-12493 C-12493 B-15050	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 B-15051
CAPT. CARD 4-74	BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-11650 A-10276	B-14566 C-12493 B-14858	B-7618 B-9166 B-12757
BIG BRAVE 6-74	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS VARI-TARGET	A-10547 D-8755 A-12399 A-13606	A-9016 A-9017 B-12569 C-12493 C-12493 C-12493 B-13020 A-14927	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 B-13019
MAGNOTRON 8-74	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-10547 D-8755 A-12399 A-13606	A-9016 A-9017 C-12567 C-12493 C-12493 C-12493 C-14703	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-14704
TOP CARD 9-74	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS	A-10547 A-9012 A-11669 	A-9016 A-9017 B-15004 C-12493 C-12493 C-12493	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-10108 (P) A-10945 (O)	A-14833 A-14834	C-14607 P A-8215 M	A-7907
A-10945 (O)	A-14834	C-15047 P A-8215 M	A-7907
A-10945 (O)	A-14834	C-14961 P A-8215 M	A-7907
A-10945 (O)	A-14834	C-15047 P A-8215 M	A-7907
A-10108 (P) A-10945 (O)	A-14834	C-14751 P A-8215 M	A-7907
A-10945 (O)	A-14834	C-14961 P A-8215 M	A-7907
A-9988 (P) A-10945 (O)	A-10633 A-14834 A-15224	C-14665 P A-1999 M A-8215 M	A-7907
A-10945 (O)	A-14834	D-15062 P A-8215 M A-9821 M	A-7766

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
DUOTRON 9-74	REPLAY	A-10547	A-9016	B-9015
	00-90 RELAY	D-8755	A-9017	B-9015
	PLAYER	A-12399	C-12569	B-12568
	TENS		C-12493	B-9166
	HUNDREDS		C-12493	B-9166
THOUSANDS		C-12493	B-9166	
TEN THOUSANDS		C-14703	B-14704	
BONUS	A-13606			
FREE FALL 9-74	BALL COUNT	A-11650	B-14566	B-7618
	TENS		C-12493	B-9166
	HUNDREDS			
	THOUSANDS		C-12493	B-9166
TEN THOUSANDS				
ROYAL PAIR 10-74	BALL COUNT	A-11669	B-14418	B-9998
	LIGHTBOX ADVANCE	A-11654	B-14101	B-14921
	TENS			
	HUNDREDS			
	THOUSANDS		C-12493	B-9166
	TEN THOUSANDS		B-15209	B-15210
ADVANCE	A-10276			
FAR OUT 12-74	REPLAY	A-10547	A-9016	B-9015
	00-90 RELAY	D-8755	A-9017	B-9015
	PLAYER	A-12399	C-15275	B-12566
	TENS		C-12493	B-9166
	HUNDREDS			
	THOUSANDS		C-12493	B-9166
	THOUSANDS		C-14923	B-9166
	TEN THOUSANDS		B-15273	B-15274
	BONUS	A-13606	A-9016	B-9015
	ADVANCE RELAY	A-9012	A-9017	B-9015

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-9988 (P) A-10945 (O)	A-10633 A-14834 A-15224	C-14665 P A-1999 M A-8215 M	A-7907
A-10945 (O)	A-14834	C-15047 P A-8215 M	A-7907
A-10945 (O)	A-14834	D-15062 P A-8215 M A-9821 M	A-8083
A-10945 (O)	A-14513 A-14834	C-15206 P A-8215 M	A-7907

NOTES

PARTS LIST

BALL KICKERS
 O = USED IN OUTHOLE R = RIGHT
 P = USED ON PLAYBOARD L = LEFT

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
OUT OF SIGHT 1-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS ADVANCE RELAY	A-10547 D-8755 A-12399 A-13606 A-9012	A-9016 A-9017 B-12569 C-12493 C-12493 C-12493 B-15273 A-9016 A-9017	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 B-15274 B-9015 B-9015
ATLANTIS 1-75	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS SEQUENCE	A-10547 D-8755 A-11669 A-15939	A-9016 A-9017 D-15004 C-12493 C-12493 C-12493 B-15470	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 B-15471
SUPER SOCCER 3-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	C-14811 C-14813 D-8755 A-12399 A-15222	A-9016 A-9017 C-15275 A-15909 A-15909 A-15909 A-15596	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-9015
SOCCER 4-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	C-14811 C-14813 D-8755 A-12399 A-15222	A-9016 A-9017 B-12569 A-15909 A-15909 A-15909 B-15596	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 B-9015
EL DORADO 4-75	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE	C-14811 C-14813 D-8755 A-11669 A-10276	A-9016 A-9017 B-15004 A-15909 A-15909 A-15909 C-15524	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 C-8966
PIN UP 4-75	BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS WOW CONTROL RELAY	A-11650	B-14566 A-15909 A-9016 A-9017	B-7618 B-9166 B-9015 B-9015
FAST DRAW 7-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS COIN BONUS	C-14811 C-14813 A-9012 A-12399 A-15611 A-13606	A-9016 A-9017 C-15275 A-15909 A-15909 A-15909 B-15601 B-13020	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-15602 B-13019

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-10945 (O)	A-14513 A-14834	C-15206 P A-8215 M	A-7907
A-15829 (O)	A-15836 A-15838	C-16091 P A-8215 M A-9821 M	A-7766
A-15827 (O) A-16083 (PR, PL)	A-15838 A-14836 (Display Unit)	C-15297 P A-8215 M	A-15606
A-15827 (O) A-16083 (PR, PL)	A-15838 A-14836 (Display Unit)	C-15297 P A-8215 M	A-15607
A-15827 (O)	A-15836 A-15838	C-15565 P A-8215 M A-16186 M	A-7907
A-10108 (P) A-10945 (O)	A-14834	C-14844 P A-8215 M	A-7907
A-15827 (O, PL) A-16045 (PR)		C-15864 P A-8215 M	A-7907

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
QUICK DRAW 7-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	C-14811 C-14813 A-9012 A-12399 A-13606	A-9017 A-9016 B-12569 A-15909 A-15909 A-15909 A-13020	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 A-13019
SPIN OUT 8-75	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ROTO	C-14811 C-14813 D-8755 A-11669 A-10293	A-9016 A-9017 B-15004 A-15909 A-15909 A-15909 C-15735	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 C-15737
TIGER 8-75	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS VARI-TARGET	A-11669 A-11654 A-13606	B-14418 B-14101 C-12493 B-13020 A-15806	B-9998 B-14921 B-9166 B-13019
"300" 10-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS COIN ADVANCE RELAY	C-14811 C-14813 A-10848 A-12399 A-15611 A-16293	A-9016 A-9017 C-15275 A-15909 A-15909 A-15909 B-15601 A-15596	B-9015 B-9015 B-12566 B-9166 B-9166 B-9166 B-15602 B-9015
TOP SCORE 10-75	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	C-14811 C-14813 A-10848 A-12399 A-16293	A-9016 A-9017 B-12569 A-15909 A-15909 A-15909 A-15596	B-9015 B-9015 B-12568 B-9166 B-9166 B-9166 B-9015
ABRA CA DABRA 11-75	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	C-14811 C-14813 D-8755 A-11669 A-16026	A-9016 A-9017 B-15004 A-15909 A-15909 A-15909 B-15943	B-9015 B-9015 B-9998 B-9166 B-9166 B-9166 B-9191
LUCKY STRIKE 11-75	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-11669 A-11654 D-8755	B-14418 B-14101 A-15909 A-15596 A-16273	B-9998 B-14921 B-9166 B-9015 B-9015

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-15827 (O, PL) A-16045 (PR)		C-15864 P A-8215 M	A-7907
A-15827 (O)	A-15836 A-15838	C-15724 P A-15734 P (Target Set) B-6617 M	A-7766
A-15829 (O)	A-15838	C-15781 P A-8215 M	A-7766
A-15827 (O) A-16083 (PR, PL)	A-15836 A-15838	C-16177 P A-8215 M	A-15606
A-15827 (O) A-16083 (PR, PL)	A-15836 A-15838	C-16177 P A-8215 M	A-15606
A-15827 (O)	A-15837 A-15839	C-15963 P A-8215 M	A-7907
A-15827 (O)	A-15836 A-15838	C-15565 P A-8215 M A-16186 M	A-7907

PARTS LIST

BALL KICKERS
 O = USED IN OUTHOLE
 P = USED ON PLAYBOARD
 R = RIGHT
 L = LEFT

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
GOLD STRIKE 1-76	BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-11650 D-8755	B-14566 A-15909 A-15596 A-16273	B-7618 B-9166 B-9015 B-9015
SPIRIT OF '76 3-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS COIN BONUS	C-14811 C-14813 D-8755 A-12399 A-15611 A-13606	A-9016 A-9017 C-15275 A-15909 A-15909 A-15909 B-15601 B-13020	A-9015 A-9015 B-12566 B-9166 B-9166 B-9166 B-15602 B-13019
PIONEER 3-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	C-14811 C-14813 D-8755 A-12399 A-13606	A-9016 A-9017 B-12569 A-15909 A-15909 A-15909 B-13020	A-9015 A-9015 B-12568 B-9166 B-9166 B-9166 B-13019
BANK SHOT 3-76	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-11669 A-11654 A-16154	B-16584 B-14101 A-15909 B-16050	B-16733 B-14921 B-9166 B-14905
SPOT POOL 3-76	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-11669 A-11654 A-16154	B-14418 B-14101 A-15909 B-16050	B-9998 B-14921 B-9166 B-14905
SURE SHOT 3-76	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	C-14811 C-14813 D-8755 A-11669 A-16154	A-9016 A-9017 B-15004 A-15909 A-15909 B-16050	A-9015 A-9015 B-9998 B-9166 B-9166 B-14905
ROYAL FLUSH 6-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-10547 A-9012 A-12399 A-15659	A-9016 A-9017 C-15275 A-15909 A-15909 A-15909 A-9016 A-9017	A-9015 A-9015 B-12566 B-9166 B-9166 B-9166 A-9015 A-9015
SHIP AHOY 6-76	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-11669 A-11654 D-9012	B-16584 B-14101 A-15909 A-9016 A-9017	B-16733 B-14921 B-9166 A-9015 A-9015

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-15827 (O)	A-15836 A-15838	C-15565 P A-8215 M A-16186 M	A-7907
A-15827 (O) A-16045 (P)		C-15873 P A-8215 M A-8215 M	A-7766
A-15827 (O) A-16045 (P)		C-15873 P A-5891 M A-8215 M	A-7766
A-15827 (O)	A-15836 A-15838	B-16049 P A-8215 M	A-7907
A-15827 (O)	A-15836 A-15838	B-16049 P A-8215 M	A-7907
A-15827 (O)	A-15836 A-15838	B-16049 P A-8215 M	A-7766
A-15827 (O) A-15828 (P)	A-15836 A-15834	C-15645 P A-5867 M B-8215 M	A-7907
A-15827 (O)	A-15836 A-15838	C-16236 P A-8215 M	A-16861

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
BUCCANEER 7-76	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-10547 A-9012 A-11669 D-8755	A-9016 A-9017 B-15004 A-15909 A-15909 A-9016 A-9017	A-9015 A-9015 B-9998 B-9166 B-9166 A-9015 A-9015
CARD WHIZ 8-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-10547 A-9012 A-12399 A-15659	A-9016 A-9017 B-12569 A-15909 A-15909 A-15909 A-9016 A-9017	A-9015 A-9015 B-12568 B-9166 B-9166 B-9166 A-9015 A-9015
NEW YORK 8-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	C-14811 C-14813 D-8755 A-12399 A-13606	A-9016 A-9017 B-12569 A-15909 A-15909 A-15909 B-13020	A-9015 A-9015 B-12568 B-9166 B-9166 B-9166 B-13019
SURF CHAMP 10-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-10547 D-8755 A-12399 A-16836	A-9016 A-9017 C-15275 A-15909 A-15909 A-15909 A-15596 A-16273	A-9015 A-9015 B-12566 B-9166 B-9166 B-9166 A-9015 A-9015
VOLLEY 10-76	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS	A-10547 A-9012 A-11669 	A-9016 A-9017 B-15004 A-15909 A-15909	A-9015 A-9015 B-9998 B-9166 B-9166
HIGH SEAS 11-76	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS CREDIT ADVANCE RELAY	A-11669 A-11654 C-14812 C-14814 A-9012	B-14418 B-14101 A-15909 A-9016 A-9017	B-9998 B-14921 B-9166 A-9015 A-9015
SURFER 11-76	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE RELAY	A-10547 D-8755 A-12399 A-16836	A-9016 A-9017 B-12569 A-15909 A-15909 A-15909 A-15596 A-16273	A-9015 A-9015 B-12568 B-9166 B-9166 B-9166 A-9015 A-9015

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-15827 (O)	A-15836 A-15838	C-16236 P B-8215 M	A-7766
A-15827 (O) A-15828 (P)	A-15834 A-15836	C-15645 P A-5867 M B-8215 M	A-7907
A-15827 (O) A-16045 (P)		C-15873 P A-5891 M B-8215 M	A-7766
A-15827 (O) A-16085 (P)	A-15836 A-15838	C-16111 P A-5891 M B-8215 M	A-7907
A-15827 (O)		C-16373 P A-8215 M	A-7766
A-15827 (O)	A-15836 A-15838	C-16236 P A-8215 M	A-16861
A-15827 (O) A-16085 (P)	A-15836 A-15838	C-16111 P A-5891 M B-8215 M	A-7907

PARTS LIST

BALL KICKERS
 O = USED IN OUTHOLE R = RIGHT
 P = USED ON PLAYBOARD L = LEFT

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
CANADA DRY 1-77	REPLAY	A-10547		
	00-90 RELAY	A-9012	A-9016	A-9015
	PLAYER	A-12399	A-9017	A-9015
	TENS		C-15275	B-12566
	HUNDREDS		A-15909	B-9166
	THOUSANDS		A-15909	B-9166
TEN THOUSANDS		A-15909	B-9166	
COIN	A-16585	B-16310	B-16311	B-16311
BONUS	A-16154	B-16312	B-16312	B-17378
JACKS OPEN 2-77	REPLAY	A-10547		
	00-90 RELAY	D-8755	A-9016	A-9015
	BALL COUNT	A-11669	A-9017	A-9015
	TENS		B-15004	B-9998
	HUNDREDS			
	THOUSANDS		A-15909	B-9166
TEN THOUSANDS		A-15909	B-9166	
SEQUENCE	A-17305	B-16387	B-16387	B-16388
KICKER 2-77	BALL COUNT	A-11669	B-17384	B-16733
	LIGHTBOX ADVANCE	A-11654	B-14101	B-14921
	TENS			
	HUNDREDS		A-15909	B-9166
	THOUSANDS			
	TEN THOUSANDS			
CREDIT	C-14812 C-14814		A-9016	A-9015
ADVANCE RELAY	D-8755	A-9017	A-9015	A-9015
TEAM ONE 3-77	BALL COUNT	A-11669	B-17384	B-16733
	LIGHTBOX ADVANCE	A-11654	B-14101	B-14921
	TENS			
	HUNDREDS		A-15909	B-9166
	THOUSANDS			
	TEN THOUSANDS			
CREDIT	C-14812 C-14814		A-9016	A-9015
ADVANCE RELAY	D-8755	A-9017	A-9015	A-9015
TARGET ALPHA 3-77	REPLAY	A-10547		
	00-90 RELAY	A-9012	A-9016	A-9015
	PLAYER	A-12399	A-9017	A-9015
	TENS		C-15275	B-12566
	HUNDREDS		A-15909	B-9166
	THOUSANDS		A-15909	B-9166
TEN THOUSANDS		A-15909	B-9166	
COIN	A-16585	B-16310	B-16311	B-16311
BONUS	A-16154	B-16312	B-16312	B-17378
SOLAR CITY 3-77	REPLAY	A-10547		
	00-90 RELAY	A-9012	A-9016	A-9015
	PLAYER	A-12399	A-9017	A-9015
	TENS		B-12569	B-12568
	HUNDREDS		A-15909	B-9166
	THOUSANDS		A-15909	B-9166
TEN THOUSANDS		A-15909	B-9166	
BONUS	A-16154	B-16312	B-16312	B-17378
BRONCO 4-77	REPLAY	A-10547		
	00-90 RELAY	A-9012	A-9016	A-9015
	PLAYER	A-12399	A-9017	A-9015
	TENS		C-15275	B-12566
	HUNDREDS		A-15909	B-9166
	THOUSANDS		A-15909	B-9166
TEN THOUSANDS		A-15909	B-9166	
COIN	A-16585	B-16310	B-16311	B-16311
BONUS	A-13606	B-16464	B-16464	B-16465

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-15827 (O)	A-15836 A-15838	C-15565 P A-8215 M A-16186 M	A-7907
A-15827 (O)		C-16410 P A-8215 M	A-7907
A-15827 (O)	A-15837 A-15839	C-15963 P A-8215 M	A-7907
A-15827 (O)	A-15837 A-15839	C-15963 P A-8215 M	A-7907
A-15827 (O)	A-15836 A-15838	C-15565 P A-8215 M A-16186 M	A-7907
A-15827 (O)	A-15836 A-15838	C-15565 P A-8215 M A-16186 M	A-7907
A-15827 (O) A-16083 (PR) A-16085 (PL)	A-16701	C-16716 P A-8215 M	A-7907

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
MUSTANG 5-77	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-10547 A-9012 A-12399 A-13606	A-9016 A-9017 B-12569 A-15909 A-15909 B-16464	A-9015 A-9015 B-12568 B-9166 B-9166 B-16465
BIG HIT 6-77	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ONES RUNS TENS RUNS HIT	A-10547 A-9012 A-11669 A-10276	A-9016 A-9017 B-15004 A-15909 A-15909 A-15909 A-15909 A-15909 B-16884	A-9015 A-9015 B-9998 B-9166 B-9166 B-9166 B-9166 B-12757
LUCKY HAND 6-77	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS CREDIT ADVANCE RELAY	A-11669 A-11654 C-14812 C-14814 A-9012	B-17384 B-14101 A-15909 A-17545 A-17546	B-16733 B-14921 B-9166 A-9015 A-9015
LUCKY CARD 7-77	BALL COUNT LIGHTBOX ADVANCE TENS HUNDREDS THOUSANDS TEN THOUSANDS CREDIT ADVANCE RELAY	A-11669 A-11654 C-14812 C-14814 A-9012	B-17384 B-14101 A-15909 A-17545 A-17546	B-16733 B-14921 B-9166 A-9015 A-9015
JUNGLE QUEEN 7-77	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS COIN BONUS	A-10547 A-9012 A-12399 A-16585 A-13606	A-9016 A-9017 C-15275 A-15909 A-15909 B-16310 B-13020	A-9015 A-9015 B-15266 B-9166 B-9166 B-16311 B-13019
JUNGLE PRINCESS 8-77	REPLAY 00-90 RELAY PLAYER TENS HUNDREDS THOUSANDS TEN THOUSANDS BONUS	A-10547 A-9012 A-12399 A-13606	A-9016 A-9017 B-12569 A-15909 A-15909 B-13020	A-9015 A-9015 B-12568 B-9166 B-9166 B-13019
CENTIGRADE 37 8-77	REPLAY 00-90 RELAY BALL COUNT TENS HUNDREDS THOUSANDS TEN THOUSANDS ADVANCE	A-10547 A-9012 A-11669 A-17484	A-9016 A-9017 B-15004 A-15909 A-15909	A-9015 A-9015 B-9998 B-9166 B-9166

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-15827 (O) A-16083 (PR) A-16085 (PL)	A-16701	C-16716 P A-8215 M	A-7907
A-15838 (O)		C-16755 P	A-7907
A-15827 (O)		C-16410 P A-8215 M	A-7907
A-15827 (O)		C-16410 P A-8215 M	A-7907
A-15827 (O, PL) A-16045 (PR)		C-16594 P A-8215 M	A-7907
A-15827 (O, PL) A-16045 (PR)		C-16594 P A-8215 M	A-7907
A-15827 (O) A-15828 (P)		C-17042 P A-8215 M	A-7907

PARTS LIST

BALL KICKERS

O = USED IN OUTHOLE R = RIGHT
P = USED ON PLAYBOARD L = LEFT

GAME & DATE OF MFG.	UNITS	GEAR & SHAFT	DISC	WIPER
JET SPIN	REPLAY	A-10547		
	00-90 RELAY	D-8755	A-9016	A-9015
	PLAYER	A-12399	A-9017	A-9015
	TENS		C-15275	B-12566
	HUNDREDS		A-15909	B-9166
	THOUSANDS			
	TEN THOUSANDS		A-15909	B-9166
	COIN	A-16585	B-17276	B-17277
	BONUS	A-13606	B-16901	B-16902
	ROTO	A-10293	C-16903	C-16931
	VARI-TARGET		A-16900	
SUPER SPIN	REPLAY	A-10547		
	00-90 RELAY	D-8755	A-9016	A-9015
	PLAYER	A-12399	A-9017	A-9015
	TENS		C-12569	B-12568
	HUNDREDS		A-15909	B-9166
	THOUSANDS			
	TEN THOUSANDS		A-15909	B-9166
	BONUS	A-13606	B-16901	B-16902
	ROTO	A-10293	C-16903	C-16931
	VARI-TARGET		A-16900	

BALL KICKERS	CONTACT KICKERS	SHIELDS (Plastic in sets only)	MOTOR CAM
A-15827 (O, P)	A-15836 A-15838	C-16967 P A-8215 M	A-7766
A-15827 (O, P)	A-15836 A-15838	C-16967 P A-8215 M	A-7766

NOTES

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
CABINET & CABINET HARDWARE			
D-13976	Cabinet — Less trim		\$170.00
D-3768	Plated steel leg, 31" long		15.00
D-8159	Left side stainless moulding		15.00
D-13978	Right side stainless moulding (start on Drop A Card)		1.20
B-14724	Metal kick plate		11.00
D-11352	Lockdown moulding slide	27	2.30
C-7215	Cashbox cover		6.00
D-7216	Cashbox		
CABINET & CABINET HARDWARE FOR "RECESSED FRONT DOOR"			
D-15117	Cabinet — Less trim		170.00
D-4337	Plated steel leg, 27" long		6.00
D-8159	Left side stainless moulding		15.00
D-13978	Right side stainless moulding		15.00
B-15114	Metal kick plate		1.20
D-15106	Lockdown moulding slide	27	7.30
C-15104	Cashbox cover		2.30
D-16345	Cashbox		6.00
D-16949	Lockdown moulding slide	27	7.60
D-16951	Lockdown moulding	27	14.00
D-17440	Cashbox		6.00
D-17441	Cashbox cover		4.00
CABINET HARDWARE COMMON TO BOTH CABINETS			
D-6038	Back "U" trim		4.00
D-6039	Back glass stop stainless trim		4.00
C-14078	Glass channel		2.00 per set
A-15811	Glass seal	26	.34
D-14008	Front moulding assembly	27	21.00
	Paint for cabinet, specify color and game, not guaranteed to match, quart only		11.00
	21" x 43" top glass		14.00
	Screened playboard		90.00
LIGHTBOXES, GLASS, DOORS AND HARDWARE			
D-8624	Lightbox — 1 player	29	72.00
D-8627	Lightbox — 2 player	29	84.00
D-10824	Lightbox — 4 player, 24" x 26" glass size	29	85.00
D-16745	Lightbox — 4 player, 26" x 26" glass size	29	85.00
D-8563	Backdoor — 1 player	29	10.00
D-8564	Backdoor — 2 player	29	11.50
D-10813	Backdoor — 4 player — used with D-10824	29	13.50
D-16758	Backdoor — 4 player — used with D-16745	29	14.50
C-8561	Door channel — 1 player	29	1.08
C-8562	Door channel — 2 & 4 players	29	1.10
A-6049	Shipping block60
A-15480	Glass wedge — 1 player	29	.16
A-15481	Glass wedge — 2 & 4 player	29	.14
	Screened lightbox glass — 1 player		33.00
	Screened lightbox glass — 2 player		35.00
	Screened lightbox glass — 4 player, 24" x 26"		37.00
	Screened lightbox glass — 4 player, 26" x 26"		40.00

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
FRONT DOORS & HARDWARE			
A-7181	Front door hinge nut strip	66	.58
A-7186	Front door lock bolt	68	.58
A-7187	Front door lock bolt guide	68	.58
A-7189	Front door lock cam guide	68	.82
B-7192	Front door coin guide trough	66	3.80
B-7193	Front door coin return housing	65	2.00
B-7194	Front door coin return cover	65	1.20
B-7196	Front door hinge	66	1.80
D-7211	Front door only, double chute	65	18.00
	Double chute front door with hinge only		20.00
	Double chute front door complete with 5¢ & 10¢ or two 25¢ slug rejectors		73.00
D-7213	Front door only, single chute	65	18.00
	Single chute front door with hinge only		20.00
	Single chute front door complete with 5¢ or 10¢ or 25¢ slug rejector		48.00
D-10066	Front door only — triple chute	65	18.00
	Triple chute front door with hinge only		20.00
	Triple chute front door complete with 5¢, 10¢ & 25¢ slug rejectors		98.00
A-7478	Front door hole plug	66	.44
A-7945	Front door coin return baffle plate	66	.30
A-10060	Front door lock strike plate	68	.40
B-10064	Front door coin return cover	65	1.40
A-11446	Coin return door	66	.78
C-14010	Lock cam guide with screws	68	.68
A-4386	Reject rod	70	.54
C-4398	Rejector saddle with A-4386 Reject rod, A-4416 Arm, switch & A-4401 Switch arm	70	13.00
A-4416	Reject arm	70	1.10
A-4524	Metal push button (red button on door)	66	.36
A-5341	Vibration damper for coin chute switch	70, 77	1.00
A-5362	Vibration damper and coin chute switch	70, 77	2.20
B-8375	Anti-cheat switch	70	1.06
B-8377	Push button switch and anti-cheat switch	70	1.96
	5¢, 10¢ or 25¢ slug rejectors		12.00
	Foreign rejectors		20.00
RECESSED FRONT DOOR & HARDWARE			
B-15068	Hinge82
D-15073	Assembly of door frame and hinge	74, 75	11.00
E-15074	Front panel	74	13.00
C-15077	Back panel	75	11.50
B-15078	Coin entrance plate retainer66
C-15079	Coin entrance housing — 1 chute	74	5.20
C-15080	Coin entrance housing — 2 chute	74	5.20
C-15081	Coin entrance housing — 3 chute	74	5.20
A-15082	Coin feed trough	78	1.36
A-15083	Coin feed trough cover	78	1.36
A-15084	Coin feed trough cover	78	1.46
A-15085	Trough guide bracket26
A-15088	Coin guide trough	76	2.50

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
RECESSED FRONT DOOR & HARDWARE cont'd.			
A-15090	Reject rod	76	1.60
A-15091	Reject shaft	76	1.50
A-15092	Reject lever	76	.26
A-15093	Reject arm	76	.16
B-15094	Reject bracket	76	.44
B-15095	Assembly reject mechanism — 1 chute	76	4.70
A-15098	Coin return door	76	.50
C-15102	Coin return housing	78	1.30
B-15101	Coin return cover — 3 chute	78	2.92
B-16344	Coin return cover — 2 chute	78	2.92
B-16342	Coin return cover — 1 chute	78	2.92
B-16338	Coin chute saddle	75, 77	2.30
A-5341	Vibration damper for coin chute switch	70, 77	1.00
A-5362	Vibration damper and coin chute switch	70, 77	2.20
B-15856	Push button switch	75, 79	1.64
B-17039	Anti-cheat switch	79	1.14
C-17367	Coin entrance housing — 1 chute	74	5.20
A-17369	Reject shaft — 1 chute	76	1.50
A-17370	Reject shaft — 2 chute	76	1.76
A-17371	Reject shaft — 3 chute	76	1.92
B-17372	Assembly reject mechanism — 1 chute	76	4.60
B-17373	Assembly reject mechanism — 2 chute	76	5.00
B-17374	Assembly reject mechanism — 3 chute	76	5.50
B-17376	Coin return cover — 1 chute	78	2.72
	Domestic rejectors		12.00
	Foreign rejectors		20.00
	Complete front door — 1 chute — less rejector		106.00
	Complete front door — 2 chute — less rejector		110.00
MISCELLANEOUS CABINET HARDWARE			
A-3775	3/8-16 x 2-3/8" leg mounting bolt24
A-3918	Lightbox mounting washer12
A-4853	Lightbox insert lock stop plate24
A-4854	Lightbox insert shoulder bushing16
C-751S	Front door lock		3.40
	Key blank58
A-12906	Dual tee nut — 3/8-16" NC thread44
	Gem lock		8.50
	Straight cam for lock36
	1-1/16" Steel ball68
	1-1/16" non-magnetic ball		3.40
	1-1/4" Catlyn ball		1.04
	10-32 x 1-1/4 truss head machine screws06
	10-32 elastic stop nut10
	#10 slotted cupped spring washer02
	5/16-18 x 1-1/4" bottom panel mounting screw10
	Leg adjuster with nuts42
	3/8" hex nuts for leg adjusters10
	3/8-16 x 3-3/4" hex head cap screws30
	3/8 "T" nuts22
	#10-32 x 1/4" button head socket cap screw for door hinge10
	Furniture glide06

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
"AG" RELAY (Specify Relay Letter and Game)			
	Assembled "AG" relay with coil, less switches		4.10
B-5363	Switch assembly "A" lockin	56	.80
B-5364	Switch assembly "A" small points	56	.76
B-5365	Switch assembly "A" large points	56	.86
B-5366	Switch assembly "B" small points	56	.76
B-5367	Switch assembly "B" large points	56	.86
B-5368	Switch assembly "C" small points	56	.98
B-10737	Switch assembly 2 "C" small points	56	1.98
"AS" RELAY (Specify Relay Letter and Game)			
	Assembled "AS" Relay with coil & switch		13.50
	Assembled "AS" Relay with coil & discs		17.00
	Assembled "AS" Relay with coil, discs & cable		20.00
INTERLOCK RELAY (Specify Relay Letter and Game)			
	Assembled complete with coils less switches		10.00
B-5363	Switch assembly "A" lockin80
B-5364	Switch assembly "A" small points76
B-5365	Switch assembly "A" large points86
B-5366	Switch assembly "B" small points76
B-5377	Switch assembly "B" large points86
B-5368	Switch assembly "C" small points98
B-10737	Switch assembly 2 "C" small points		1.98
COILS			
A-489	Relay coil	19	2.24
A-1118	Relay bank coil		1.42
A-1119	Relay bank coil		1.50
A-1496	Solenoid coil	7, 8, 44, 81	2.40
A-4893	Solenoid coil	2, 3, 44, 81	2.50
A-5141	Solenoid coil	12, 14, 81	2.80
A-5194	Solenoid coil	10, 30, 31, 32, 33, 34, 42, 43, 80, 81	2.30
A-5195	Solenoid coil	80, 81	2.90
A-5196	Solenoid coil	81	3.70
A-5197	Solenoid coil	40, 81	3.60
A-5662	Relay coil		1.90
A-5723	Solenoid coil		2.30
A-6698	Relay coil		2.40
A-7677	Relay coil	67	2.40
A-7800	Solenoid coil	81	3.20
A-9479	Solenoid coil	81	4.60
A-9733	Relay coil		2.10
A-9735	Relay coil		2.20
A-9736	Relay coil	75	2.30
A-9738	Relay coil		2.10
A-9740	Relay coil	18	2.30
A-9741	Relay coil		3.50
A-9742	Relay coil		2.00
A-9746	Relay coil		2.20
A-11058	Relay coil		2.90
A-15259	Solenoid coil	49, 81	1.76
A-15359	Relay bank coil		1.76

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
	COILS cont'd.		
A-15555	Solenoid coil	81	2.76
A-16251	Relay coil		2.10
A-16890	Relay coil		2.16
A-17564	Relay coil		2.16
	 RESISTORS, CONDENSERS & RECTIFIERS		
	6 OHM 2 Watt48
	47 OHM 10 Watt48
	75 OHM 10 Watt26
	470 OHM 2 Watt48
	25 Micro-Farad		1.80
	47 Micro-Farad56
	500 Micro-Farad		1.28
	1000 Micro-Farad		1.70
	100 P.I.V. Rectifier20
	 FUSES		
	5 AMP12
	7½ AMP10
	10 AMP10
	12 AMP40
	15 AMP10
	½ AMP slo-blo60
	1 AMP slo-blo66
	2 AMP slo-blo60
	5 AMP slo-blo48
	10 AMP slo-blo40
#350-308	Fuse holder34
	 MOTORS		
B-7760	Motor — 60 Hz.		16.50
B-11550	Motor — 50 Hz.		16.50
	 TRANSFORMERS		
B-3235	115 V. 60 Hz.		36.00
B-4277	115 V. 60 Hz.		34.00
B-6183	115 V. 60 Hz.		39.00
B-7986	118 V. Isolation; 115-230 V. 50-60 Hz.		72.00
B-8091	Twin Pri. 115-230 V. 50-60 Hz.		46.00
B-8659	118 V. Isolation; 115-230 V. 50-60 Hz.		72.00
B-8660	Twin Pri. 115-230 V. 50-60 Hz.		42.00
B-13396	125-160-220 V. 50 Hz.		60.00
B-14602	125-160-220 V. 50 Hz.		46.00
B-16722	230 V. Pri. 50-60 Hz.		66.00
B-17029	230 V. Pri. 50-60 Hz.		66.00
B-17482	230 V. Pri. 50-60 Hz.		72.00
	 LAMPS		
#4420
#45544

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
LAMP SOCKETS			
#131	Pop bumper light socket24
A-1363	Lightbox socket (short)20
A-2913	Playboard socket20
A-2914	Playboard socket20
A-2915	Playboard socket24
A-2916	Playboard socket22
A-3030	Playboard and lightbox socket24
A-3561	Playboard socket, double lug28
A-4330	Lightbox socket (long)16
A-4762	Playboard socket22
A-7704	Playboard socket32
A-7746	Playboard socket32
A-15858	Front door socket40
A-16002	Playboard socket22
RUBBER PARTS			
#E-15	Rubber tip	24	.06
#986	Rubber grommet — drop target	16	.04
#1872	Rubber plunger tip	26	.10
#2752	Rubber grommet — chime08
A-1344	Rubber rebound	24	.32
A-5240	Rubber grommet06
A-10217	Rubber ring 3/8" #108
A-10218	Rubber ring 3/4" #208
A-10219	Rubber ring 1" #10	4	.10
A-10220	Rubber ring 1-1/2" #1112
A-10221	Rubber ring 2" #1214
A-10222	Rubber ring 2-1/2" #1416
A-10223	Rubber ring 3" #1620
A-10224	Rubber ring 3-1/2" #1822
A-10225	Rubber ring 4" #2030
A-10226	Rubber ring 5" #2552
A-13149	Flat beaded rubber ring — red only26
A-13151	Rubber ring — Jumbo flipper — red only22
A-14793	Rubber ring — mini post — 23/64" dia.06
A-15705	Rubber ring — mini post — 27/64" dia.06
A-17493	Rubber ring — 7/16" #27	21	.12

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
PLAYBOARD PLASTICS (SPECIFY COLOR)			
A-945	Plastic hole cover	8	.16
A-2305	Light shade 15/16"08
A-2968	Light shade 1-1/8"12
A-8845	3/4" dia. playboard insert16
A-8846	7/8" dia. playboard insert18
A-8847	1" dia. playboard insert20
A-8848	1-3/16" dia. playboard insert22
A-9374	Plastic target	21	.26
A-9393	Plastic guide rail, 1-1/2" centers, single apron20
A-9394	Plastic guide rail, 1-1/2" centers, double apron22
A-9395	Plastic guide rail, 2-1/8" centers, single apron22
A-9396	Plastic guide rail, 2-1/8" centers, double apron22
A-9397	Plastic guide rail, 2-1/2" centers, single apron22
A-9398	Plastic guide rail, 2-1/2" centers, double apron22
A-10303	Light shade 1-7/8"06
A-11094	Plastic target	21	.36
C-11561	Plastic post 1" – white	25	.14
C-11562	Plastic post 1-3/16" – white	25	.16
D-11966	Rollover insert	22	.42
D-11968	Rollover button	22	.26
A-14487	Split post base – white	25	.06
A-14488	Split post cap – white	25	.06
C-15646	Mini post rollover guide 1-1/2"	25	.32
C-15647	Mini post rollover guide 2"	25	.34
C-15648	Mini post rollover guide 2-1/2"	25	.38
C-15707	Hole base plate	14	.20
C-15708	Hole switch arm	14	.18
C-17492	Siamese post	21	.16
WIRE			
	Covered pigtail wire, per foot12
	Bare pigtail wire, per foot10
	Stranded 18 ga. bare, per foot08
	Stranded 18 ga. covered, per foot10
	Stranded 22 ga. covered wire, per foot08
SCORE CARDS			
	Score cards		2.40 per set
SCHEMATIC DIAGRAMS			
	Schematic diagrams		2.00
CARTONS			
	Single player carton and fillers		24.00
	2 player carton and fillers		29.00
	4 player carton and fillers		29.00
	Recessed front door 1 p. carton and fillers		24.00
	Recessed front door 2 p. carton and fillers		29.00
	Recessed front door 4 p. carton and fillers		29.00
LUBRICANT			
A-16324	White lube approx. 1/2 oz. tube96
A-16325	Black lube approx. 1/2 oz. tube96

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
HARDWARE			
NUTS			
	3-48 Hex		1.40 per 100
	5-40 Hex		1.10 per 100
	6-32 Hex		1.10 per 100
	8-32 Hex		1.20 per 100
	10-32 Hex		1.40 per 100
	1/4-20 Hex		.06
	3/8-16 Hex (leg levellers)		.10
	6-32 Elastic stop		.10
	8-32 Elastic stop aluminum		.10
	8-32 Elastic stop steel		.06
	10-32 Elastic stop		.10
	10-32 Wing nut		.20
	6-32 "T" nuts		.20
	8-32 "T" nuts		.20
	SC-125 Palnut		.02
	PS-094032 Pushnut		.88 per 100
	3/8-16 "T" nut		.22
A-12906	Dual "T" nut - 3/8-16		.44
WASHERS			
	3 Flat Brass		.84 per 100
	4 Flat		.50 per 100
	5 Flat		.60 per 100
	6 Flat		.60 per 100
	6 Brass		.80 per 100
	6 Flat Nickel plated		.64 per 100
	8 Flat		.60 per 100
	8 Flat Brass		1.00 per 100
	10 Flat		.70 per 100
	12 Flat		.98 per 100
	1/4 Flat		1.00 per 100
	3/8 Flat		.04
	Fibre - 9/64 I.D., 9/32 O.D., .046 thick		.02
	Nylon - 5/32 I.D., 3/8 O.D., .060 thick		.02
LOCKWASHERS			
	3-48 Internal tooth		.70 per 100
	5-40 External tooth		.70 per 100
	6-32 External tooth		.60 per 100
	8-32 External tooth		.60 per 100
	8-32 Internal tooth		.38 per 100
	10-32 External tooth		.70 per 100
	10-32 Cupped spring washers		.04
	12 External tooth		.80 per 100
	1/4-20 Split ring		.04
	5/16 External tooth		.90 per 100

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
RETAINING RINGS			
#5133-12	Retaining Ring02
#5133-15	Retaining Ring02
#5133-18	Retaining Ring04
#5133-25	Retaining Ring04
#5133-31	Retaining Ring04
#5133-37	Retaining Ring06
#5105-62	Retaining Ring04
SPRING WASHERS			
	#3502-20-2104
	#3502-24-2606
	#3522-10-0006
A-10703	Spring washer02
A-15910	Spring washer02
MACHINE SCREWS			
	3-48 x 3/16 R.H.M.S.		1.60 per 100
	3-48 x 1/2 Fil. H.M.S.		1.86 per 100
	3-48 x 5/8 Fil. H.M.S.		1.78 per 100
	3-48 x 3/4 Fil. H.M.S.		2.10 per 100
	3-48 x 7/8 Fil. H.M.S.		2.16 per 100
	3-48 x 1 Fil. H.M.S.		2.32 per 100
	3-48 x 1-1/8 Fil. H.M.S.		2.60 per 100
	3-48 x 1-3/16 Fil. H.M.S.		2.92 per 100
	3-48 x 1-7/16 Fil. H.M.S.		3.80 per 100
	3-48 x 1-1/2 Fil H.M.S.		3.70 per 100
	3-48 x 1-9/16 Fil. H.M.S.		3.90 per 100
	5-40 x 3/16 R.H.M.S. — Sems		2.50 per 100
	5-40 x 1/4 Fil. H.M.S. — Sems		3.46 per 100
	5-40 x 3/8 R.H.M.S.		1.10 per 100
	5-40 x 3/8 R.H.M.S. — Sems		3.80 per 100
	5-40 x 1/2 R.H.M.S.		1.40 per 100
	5-40 x 5/8 R.H.M.S.		1.00 per 100
	5-40 x 3/4 R.H.M.S.		1.20 per 100
	5-40 x 7/8 R.H.M.S.		1.26 per 100
	5-40 x 7/8 R.H.M.S. — Sems		2.60 per 100
	5-40 x 1 R.H.M.S.		1.38 per 100
	5-40 x 1 R.H.M.S. — Sems		2.40 per 100
	5-40 x 1-1/8 R.H.M.S.		1.80 per 100
	5-40 x 1-1/8 R.H.M.S. — Sems		2.40 per 100
	5-40 x 1-1/4 R.H.M.S.		2.60 per 100
	5-40 x 1-1/4 R.H.M.S. — Sems		2.80 per 100
	5-40 x 1-3/8 R.H.M.S.		2.98 per 100
	5-40 x 1-1/2 R.H.M.S.		2.90 per 100
	5-40 x 1-5/8 R.H.M.S.		3.00 per 100
	5-40 x 1-3/4 R.H.M.S.		3.30 per 100
	5-40 x 1-7/8 R.H.M.S.		2.50 per 100
	5-40 x 2 R.H.M.S.		3.30 per 100

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
MACHINE SCREWS cont'd.			
	6-32 x 3/16 R.H.M.S.		2.54 per 100
	6-32 x 1/4 Cup Point Set Screw		4.30 per 100
	6-32 x 1/4 R.H.M.S.		1.00 per 100
	6-32 x 1/4 R.H.M.S. — Sems		2.36 per 100
	6-32 x 5/16 R.H.M.S.		1.04 per 100
	6-32 x 5/16 R.H.M.S. — Sems		2.14 per 100
	6-32 x 1/2 R.H.M.S.		1.20 per 100
	6-32 x 1/2 R.H.M.S. — Sems		2.22 per 100
	6-32 x 3/4 R.H.M.S.		1.50 per 100
	6-32 x 7/8 Pan H.M.S. (self tapping)		2.90 per 100
	6-32 x 1 R.H.M.S.		1.00 per 100
	6-32 x 1/4 Hex H.M.S. — Sems		2.80 per 100
	6-32 x 1/4 Flat H.M.S. — Undercut		1.40 per 100
	6-32 x 1/4 Flat H.M.S.		1.40 per 100
	6-32 x 5/16 Hex H.M.S. — Sems		3.14 per 100
	6-32 x 3/8 Flat H.M.S.		1.40 per 100
	6-32 x 1/2 Flat H.M.S.		1.40 per 100
	6-32 x 5/8 Flat H.M.S.		1.60 per 100
	6-32 x 1-1/8 Oval H.M.S.		2.28 per 100
	6-32 x 1-1/8 Flat H.M.S.04
	8-32 x 3/16 R.H.M.S.		1.56 per 100
	8-32 x 3/16 R.H.M.S. — Sems		3.00 per 100
	8-32 x 1/4 R.H.M.S.		1.20 per 100
	8-32 x 1/4 R.H.M.S. — Sems		2.38 per 100
	8-32 x 5/16 R.H.M.S. — Sems		2.38 per 100
	8-32 x 3/8 R.H.M.S. — Sems		2.00 per 100
	8-32 x 3/8 R.H.M.S. — Sems — Brass		3.60 per 100
	8-32 x 7/16 R.H.M.S.		1.34 per 100
	8-32 x 7/16 R.H.M.S. — Sems		2.46 per 100
	8-32 x 1/2 R.H.M.S. — Sems		2.00 per 100
	8-32 x 5/8 R.H.M.S.		1.20 per 100
	8-32 x 3/4 R.H.M.S.		1.20 per 100
	8-32 x 3/4 Flat H.M.S.		1.60 per 100
	8-32 x 1 Flat H.M.S.		2.10 per 100
	8-32 x 1/4 Hex H.M.S.		1.40 per 100
	8-32 x 1/4 Hex H.M.S. — Sems		2.40 per 100
	8-32 x 3/8 Hex H.M.S.		1.60 per 100
	8-32 x 3/8 Hex H.M.S. — Sems		2.32 per 100
	8-32 x 1/4 Cup Point Set Screw06
	8-32 x 1/4 Socket Head Cap Screw08
	8-32 x 1/4 Pan H.M.S.02
	8-32 x 1/4 Pan H.M.S. — Sems		2.40 per 100
	8-32 x 3/8 Hex Head Cup Point Set Screw10

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
MACHINE SCREWS cont'd.			
	10-32 x 5/16 R.H.M.S. — Sems04
	10-32 x 3/8 R.H.M.S. — Sems04
	10-32 x 3/8 Hex H.M.S.04
	10-32 x 3/8 Hex H.M.S. — Sems06
	10-32 x 3/8 Slotted 1/4" Hex Head Cup Point Screw10
	10-32 x 1/4 Button Head Socket Cap Screw10
	10-32 x 1-1/4 Truss H.M.S.06
	1/4-20 x 5/16 Cup Point Set Screw10
	1/4-20 x 5/8 Socket Head Cap Screw10
	5/16-18 x 1-1/4 Fil. H.M.S.10
	3/8-16 x 3-3/4 Hex Head Cap Screw30
WOOD AND SHEET METAL SCREWS			
	4 x 3/8 R.H.S.M.S.		1.32 per 100
	5 x 3/8 R.H.S.M.S.94 per 100
	5 x 3/8 R.H.W.S.		1.00 per 100
	5 x 1/2 R.H.W.S.		1.42 per 100
	5 x 3/4 R.H.W.S.		1.60 per 100
	5 x 7/8 R.H.W.S.		1.80 per 100
	5 x 1 R.H.W.S.		1.92 per 100
	5 x 1-1/8 R.H.S.M.S.		1.68 per 100
	5 x 1-1/4 R.H.W.S.		1.90 per 100
	5 x 1-1/2 R.H.W.S.		1.80 per 100
	6-20 x 3/8 Hex W.H.S.		2.00 per 100
	6 x 3/8 R.H.W.S.		1.10 per 100
	6 x 3/8 R.H.S.M.S. Nickel		1.20 per 100
	6 x 3/8 Truss Hd. S.M.S.90 per 100
	6 x 1/2 R.H.S.M.S.		1.20 per 100
	6 x 1/2 Pan H.S.M.S.		1.30 per 100
	6 x 1/2 W.H.S.M.S.		1.50 per 100
	6 x 5/8 R.H.W.S.		1.50 per 100
	6 x 5/8 R.H.S.M.S.		1.26 per 100
	6 x 5/8 Pan H.S.M.S.		1.10 per 100
	6 x 3/4 R.H.S.M.S.		1.28 per 100
	6 x 3/4 Hex W.H. S.M.S.		1.26 per 100
	6 x 3/4 Pan H.S.M.S.		1.50 per 100
	6 x 3/4 W.H. S.M.S.		1.40 per 100
	6 x 7/8 Oval H.W.S.		1.80 per 100
	6 x 1 R.H.S.M.S.		1.52 per 100
	6 x 1 R.H.W.S.		2.00 per 100
	6 x 1-1/4 R.H.W.S.		2.62 per 100
	6 x 1-1/2 R.H.S.M.S. — Nickel Plate		2.30 per 100
	6 x 1-5/8 R.H.S.M.S. — Nickel Plate		2.22 per 100
	6 x 1-3/4 R.H.W.S. — Nickel Plate		2.80 per 100

PRICE LIST

Arranged by Groups of Related Parts

Part No.	Description	Page	Price
WOOD AND SHEET METAL SCREWS cont'd.			
	8 x 1/2 R.H.W.S.		1.30 per 100
	8 x 5/8 R.H.W.S.		1.90 per 100
	8 x 3/4 R.H.W.S.		2.00 per 100
	8 x 3/4 Flat H.W.S.		1.90 per 100
	8 x 1 R.H.W.S.		2.26 per 100
	8 x 1 Flat H.W.S.		2.42 per 100
	8 x 1 R.H.S.M.S.		1.78 per 100
	8 x 1-1/4 R.H.W.S.		2.20 per 100
	8 x 1-1/2 R.H.W.S. — Nickel Plate		3.34 per 100
	8 x 1-5/8 W.H.W.S. — Nickel Plate		2.90 per 100
	8 x 2 R.H.W.S. — Nickel Plate06
	8 x 2-1/4 Oval H.W.S.06
	8 x 2-1/2 Oval H.W.S.06
PINS			
	1/16 x 1/2 Cotter Pin36 per 100
	3/32 x 1/4 Roll Pin04
	3/32 x 5/8 Roll Pin04
	3/32 x 1 Cotter Pin04
	1/8 x 1/2 Split Roll Pin04
	3/16 x 3/4 Split Roll Pin04
RIVETS			
	1/8 x 1/8 Brass Nickel Plated80 per 100
	1/8 x 5/32 Brass80 per 100
	1/8 x 3/16 Brass80 per 100
	1/8 x 7/32 Brass Nickel Plated90 per 100
	1/8 x 1/4 Brass82 per 100
	1/8 x 1/4 Steel82 per 100
	1/8 x 9/32 Brass		1.00 per 100
	1/8 x 11/32 Brass		1.06 per 100
	1/8 x 3/8 Brass		1.46 per 100
	1/8 x 13/32 Brass		1.16 per 100
	1/8 x 7/16 Brass		1.28 per 100
	1/8 x 15/32 Brass		1.24 per 100
	1/8 x 1/2 Brass		1.44 per 100
	1/8 x 17/32 Brass		1.40 per 100
	1/8 x 9/16 Brass		1.30 per 100
	1/8 x 19/32 Brass		1.20 per 100
	3/32 x 1/4 Brass80 per 100
A-1114	Brass80 per 100
A-1115	Brass		1.00 per 100
A-1132	Brass92 per 100
A-4071	Stainless Steel		1.66 per 100
A-4907	Brass82 per 100
A-14065	Stainless Steel		1.20 per 100

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-127	Formed switch blade	63	.18
A-154	Formed switch blade	8	.18
A-256	Drive arm zero stop	30, 31, 32, 33, 34	.22
A-262	Drive coil plunger	16, 17, 52	.92
A-264	Drive coil spring	40	.18
A-266	Coil housing case	15, 16, 40	.82
A-267	Coil housing cover86
A-272	Reset arm plunger	7, 8, 10, 12, 32, 34, 42, 43, 44	.86
A-278	Spacer10
A-295	Coil mounting bracket	7, 8, 10	.30
A-307	Wiper finger spring	37	.06
A-324	Armature	18, 60	.24
A-334	Shoulder pin08
A-347	Outside barrel spring	26	.18
A-348	Shooter spring	26	.16
A-356	Tilt bob	84	.68
A-358	Tilt bob striker plate	84	.58
A-391	.008 switch blade 1st cut	83	.14
A-392	.010 switch blade 1st cut	83	.14
A-393	.012 switch blade 1st cut	83	.14
A-394	.016 switch blade 1st cut	83	.14
A-395	.020 switch blade 1st cut	83	.14
A-396	.008 switch blade 2nd cut	83	.14
A-397	.010 switch blade 2nd cut	83	.14
A-398	.012 switch blade 2nd cut	83	.14
A-399	.016 switch blade 2nd cut	83	.14
A-400	.020 switch blade 2nd cut	83	.14
A-401	.008 switch blade 3rd cut	83	.14
A-402	.010 switch blade 3rd cut	83	.14
A-403	.012 switch blade 3rd cut	83	.14
A-404	.016 switch blade 3rd cut	83	.14
A-405	.020 switch blade 3rd cut	83	.14
A-406	.008 switch blade 4th cut	83	.14
A-407	.010 switch blade 4th cut	83	.14
A-408	.012 switch blade 4th cut	83	.14
A-409	.016 switch blade 4th cut	83	.14
A-410	.020 switch blade 4th cut	83	.14
A-411	.008 switch blade 5th cut	83	.14
A-412	.010 switch blade 5th cut	83	.14
A-413	.012 switch blade 5th cut	83	.14
A-414	.016 switch blade 5th cut	83	.14
A-415	.020 switch blade 5th cut	83	.14
A-416	.008 switch blade 7th cut	83	.14
A-417	.010 switch blade 7th cut	83	.14
A-418	.012 switch blade 7th cut	83	.14
A-419	.016 switch blade 7th cut	83	.14
A-420	.020 switch blade 7th cut	83	.14
A-421	.008 switch blade 1st cut less tail	83	.14
A-422	.010 switch blade 1st cut less tail	83	.14
A-423	.012 switch blade 1st cut less tail	83	.14
A-424	.016 switch blade 1st cut less tail	83	.14

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-425	.020 switch blade 1st cut less tail	83	.14
A-426	.008 switch blade 2nd cut less tail	83	.14
A-427	.010 switch blade 2nd cut less tail	83	.14
A-428	.012 switch blade 2nd cut less tail	83	.14
A-429	.016 switch blade 2nd cut less tail	83	.14
A-430	.020 switch blade 2nd cut less tail	83	.14
A-431	.008 switch blade 3rd cut less tail	83	.14
A-432	.010 switch blade 3rd cut less tail	83	.14
A-433	.012 switch blade 3rd cut less tail	83	.14
A-434	.016 switch blade 3rd cut less tail	83	.14
A-435	.020 switch blade 3rd cut less tail	83	.14
A-436	.008 switch blade 4th cut less tail	83	.14
A-437	.010 switch blade 4th cut less tail	83	.14
A-438	.012 switch blade 4th cut less tail	83	.14
A-439	.016 switch blade 4th cut less tail	83	.14
A-440	.020 switch blade 4th cut less tail	83	.14
A-441	.008 switch blade 5th cut less tail	83	.14
A-442	.010 switch blade 5th cut less tail	83	.14
A-443	.016 switch blade 5th cut less tail	83	.14
A-444	.016 switch blade 5th cut less tail	83	.14
A-445	.020 switch blade 5th cut less tail	83	.14
A-446	.008 switch blade 7th cut less tail	83	.14
A-447	.010 switch blade 7th cut less tail	83	.14
A-448	.012 switch blade 7th cut less tail	83	.14
A-449	.016 switch blade 7th cut less tail	83	.14
A-450	.020 switch blade 7th cut less tail	83	.14
A-451	Side lug	82	.14
A-453	Fibre lifter	82	.12
A-454	Fibre lifter	82	.12
A-455	Fibre lifter	82	.12
A-456	Fibre lifter	82	.12
A-457	Fibre lifter	82	.12
A-458	Fibre lifter	82	.12
A-459	Fibre lifter	82	.12
A-460	Fibre lifter	82	.12
A-461	Fibre lifter	82	.12
A-462	Fibre lifter	82	.12
A-463	Switch blade separator, 1/16" thick	82	.08
A-464	Switch blade separator, 1/32" thick	82	.08
A-465	Switch cover plate	16, 47, 49, 82	.08
A-466	Silver contact point	83	.22
A-468	Silver contact point	83	.12
A-471	Switch insulator tubing 5/32" to 29/32" long inclusive	82	.08
A-477	Fish paper blade, 7th cut	82	.10
A-489	Coil	19	2.24
A-517	Drive pawl spring	15, 16, 19, 30-34, 52, 53	.12
A-557	Interlock relay housing	18, 60, 67	.90
A-574	Spring	18, 60	.12
A-590	Kicker return spring	2, 3, 42, 43	.08
A-613	Nylon bell tip		.24

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-681	Switch mounting bracket34
A-691	Rivet10
A-728	Bank armature spring	53	.10
A-729	Lock-in pawl spring, actuating arm spring	32, 53	.08
A-743	Tilt switch weight26
A-745	Tilt switch guard	70	.18
A-779	Spring	14	.06
A-786	Formed switch blade	63	.20
A-818	Allen head "T" wrench	85	5.00
A-918	Formed switch blade	63	.20
A-945	Plastic hole cover	8	.16
A-1049	Adjustable jam stop	30, 31, 33	.26
A-1050	Adjustable open end stop	30, 33	.26
A-1058	Subtract pawl shoulder screw	32, 34	.18
A-1059	Reset arm shoulder screw	33	.20
A-1060	Subtract pawl spring	32, 34	.10
A-1061	Reset arm spring	30, 31, 32, 34	.10
A-1070	Reset torsion spring	32, 34	.46
A-1076	Shoulder pin10
A-1082	Hairpin fastener	67	.06
A-1102	Drive coil housing base	30	.68
A-1103	Drive coil housing cover76
A-1114	Brass disc rivet80 per 100
A-1115	Brass disc rivet	41	1.00 per 100
A-1118	Coil		1.42
A-1119	Coil		1.50
A-1132	Brass armature rivet92 per 100
A-1179	Shoulder pin10
A-1190	Drive coil plunger	31, 32, 33, 34	.68
A-1195	Steel backing blade	82	.10
A-1216	Bumper switch mounting bracket	2	.34
A-1279	Reset arm with pin for link	32, 34, 36	1.28
A-1309	Rebound bracket and pin	24	.64
A-1316	Metal ring and shaft assembly	2	1.42
A-1344	Large rebound rubber	24	.32
A-1345	Reset lock-in pawl	32	.64
A-1363	Bayonet socket (short)24
A-1451	Motor switch dog	63	.24
A-1452	Switch dog bracket	63	.36
A-1487	Bell plunger	80	.68
A-1496	Coil	7, 8, 30, 31, 44, 81	2.40
A-1636	Plunger return spring	7, 8, 10, 44	.06
A-1671	Index pawl spring	70, 75, 77	.08
A-1672	Fibre lifter	82	.16
A-1698	Backing blade	82	.10
A-1826	Switch ground plate	82	.10
A-1843	Hex head shoulder screw	52	.20
A-1999	Metal shield 3-1/8" center60
A-2011	Drive arm shoulder screw	30, 31, 32, 34, 44, 70	.24
A-2040	Small oval head silver point	83	.12
B-2091	5" bell shell	80	2.86

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-2305	Light shade10
A-2314	.008 switch blade 6th cut	83	.14
A-2315	.010 switch blade 6th cut	83	.14
A-2316	.012 switch blade 6th cut	83	.14
A-2317	.016 switch blade 6th cut	83	.14
A-2318	.020 switch blade 6th cut	83	.14
A-2319	.008 switch blade 6th cut less tail	83	.14
A-2320	.010 switch blade 6th cut less tail	83	.14
A-2321	.012 switch blade 6th cut less tail	83	.14
A-2322	.016 switch blade 6th cut less tail	83	.14
A-2323	.020 switch blade 6th cut less tail	83	.14
A-2408	Nylon flipper shaft bushing	12, 13	.36
A-2426	Nylon flipper shaft bushing (cut)	13	.46
A-2438	Drive pawl shoulder pin	32	.16
A-2484	Subtract pawl	34, 36	.58
A-2547	Cam link	7, 8, 10, 44	.36
A-2660	Fish paper blade	82	.10
A-2662	Insulating yoke (Bakelite)	2, 3, 5	.40
A-2663	Plunger	2, 3	.64
A-2728	Drive lever tip	30, 31, 32, 33, 34	.22
A-2820	Fibre reset link	32, 34, 36	.36
A-2913	Bayonet socket20
A-2914	Bayonet socket20
A-2915	Bayonet socket24
A-2916	Bayonet socket22
A-2968	Light shade12
A-2973	Key hanger20
A-2988	Plunger	40	.82
A-3009	Flipper switch guard14
A-3030	Bayonet socket24
A-3232	Plunger spring	44	.16
B-3235	Transformer		36.00
A-3287	Arch gate46
A-3288	Arch gate spring36
A-3289	Arch gate pin12
A-3290	Arch gate assembly	24	1.32
A-3309	Formed switch blade	63	.20
A-3328	Flipper return spring (Left)	12, 13	.58
A-3329	Flipper return spring (Right)	12, 13	.58
A-3336	Shoulder pin16
A-3408	Contact kicker coil and bracket assembly	10	4.60
A-3409	Contact kicker coil and bracket assembly		4.60
A-3561	Bayonet socket28
D-3768	Metal cabinet leg		6.20
A-3775	3/8-16 x 2-3/8" leg mounting bolt24
A-3891	Coil		1.88
A-3896	Nylon bushing	81	.16
A-3898	Coil stop and mounting		1.02
A-3918	Lightbox mounting bolt washer12
B-4068	Bank pivot support, right	52, 53	1.22
B-4069	Bank pivot support, left	52, 53	1.22

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-4071	Stainless steel armature rivet		1.66 per 100
C-4128	Interlock relay frame	60	1.00
A-4184	Drive pawl lift	40	.36
A-4185	Stop pawl lift	40	.36
A-4188	Guide bracket	40	.98
A-4190	Stop pawl shoulder bearing16
A-4191	Drive pawl shoulder pin26
A-4271	Ball strike plate and blade		1.34
A-4277	Transformer		34.00
A-4330	Bayonet socket16
D-4337	Metal cabinet leg		6.00
A-4345	Target blade only	41	.18
A-4346	Backing plate for roto unit18
A-4374	Switch arm limit plate16
A-4386	Reject rod	70	.52
C-4398	Rejector saddle with A-4386 reject rod, A-4416 reject arm, switch and A-4400 switch arm . . .	70	14.00
A-4400	5¢ or 10¢ coin switch arm	70	.46
A-4401	25¢ coin switch arm	70	.48
A-4416	Reject arm	70	1.10
A-4515	Contact adjuster	85	1.54
A-4524	Metal red push button	66	.36
A-4546	Nylon bushing84
A-4583	Drive coil housing with stop		1.72
A-4584	Drive coil housing with stop		1.72
A-4634	"Z" coil mounting bracket with stop	7, 8, 10	1.36
A-4637	Reset arm adjustable stop	52, 53	.22
A-4701	Terminal lug06
A-4705	Metal shield, rollunder	20	.76
A-4706	Gate, wire form	20	.26
A-4726	Allen head "T" wrench	85	5.00
A-4758	Lightbox insert hinge pivot	29	.46
A-4759	Lightbox insert hinge pin	29	.48
A-4762	Bayonet socket22
C-4805	Radius arch channel		1.56
D-4806	Radius arch plate cover (state color and game) . .		7.10
A-4826	Insert stop bracket36
A-4830	Formed switch blade	20	.24
A-4831	Ball guide rail24
A-4832	Ball guide rail24
A-4833	Ball guide rail46
A-4853	Lightbox insert lock stop plate24
A-4854	Lightbox insert lock shoulder bushing16
A-4862	Coil stop with aluminum nut	47, 81	.76
A-4869	Metal shield, rollunder	20	.76
A-4893	Coil	2, 3, 44, 81	2.50
A-4907	Lug rivet	41, 50, 51	.82 per 100
A-4958	Rollover wire assembly	23	.46
A-4959	Rollover wire assembly	23	.46
A-4960	Rollover wire assembly	23	.46
A-4961	Rollover wire assembly	23	.46

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-4965	Armature spring, interlock relay	60	.16
A-4977	1/16" switch blade separator	57	.10
A-4978	3/64" switch blade separator	57	.10
A-4979	Override blade retainer	57	.10
A-4980	Override blade spacer	57	.10
A-4981	Switch cover plate, 1/4" centers	47, 49, 57	.10
A-4983	.008 switch blade	57	.14
	.008 switch blade with A-466 point		.38
	.008 switch blade with A-2040 point		.26
	.008 switch blade with A-5332 point (For "C" switch)		.32
A-4984	.010 switch blade	57	.14
	.010 switch blade with A-466 point		.38
	.010 switch blade with A-2040 point		.26
A-4985	.008 lock-in blade	57	.14
	.008 lock-in blade with A-2040 point		.26
A-4986	.008 override blade	57	.14
A-4987	Lock-in backing blade	57	.14
A-4988	"AG" relay armature		.42
C-4989	"AG" relay housing	56, 60	1.14
C-4990	"AG" relay armature arm insulator		.28
A-5024	Flipper stop bracket	12, 18	.46
A-5064	Plastic slip-in core 1-21/32"	2, 3, 7, 8, 10, 12, 14, 34, 44, 81	.26
A-5065	Plastic slip-in core 1-7/8"	17, 30-thru-34, 42, 43, 81	.26
A-5081	Spring	56, 60	.10
A-5141	Coil	12, 14, 81	2.80
A-5142	Plastic slip-in core 2-3/4"	80, 81	.30
A-5147	Flipper coil mounting bracket	12	.42
A-5148	Flipper coil mounting bracket	12	.64
A-5172	Plastic slip-in core 2-1/2"	15, 16, 40, 52, 81	.26
A-5190	Assembly of A-5141 coil and mounting bracket	12	6.50
A-5191	Assembly of A-5141 coil and mounting bracket		6.50
A-5194	Coil	10, 31, 32, 33, 34, 42, 43, 80, 81	2.30
A-5195	Coil	80, 81	2.90
A-5196	Coil	81	3.70
A-5197	Coil	40, 81	3.60
A-5219	Light shield		.26
A-5240	Rubber grommet	80	.06
A-5242	Reset lever	30, 31, 33, 36	1.04
A-5246	Plunger washer	26	.04
A-5255	Nylon lifter	82	.08
A-5256	Nylon lifter	82	.08
A-5257	Nylon lifter	82	.08
A-5258	Nylon lifter	82	.08
A-5259	Nylon lifter	82	.08
A-5260	Nylon lifter	82	.08
A-5261	Nylon lifter	82	.08
A-5262	Nylon lifter	82, 83	.08
A-5263	Nylon lifter	82	.08
A-5264	Nylon lifter	82	.08
C-5269	"AG" relay armature arm insulator		.22

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-5272	Flat metal rail58
A-5305	Assembly of A-5194 coil and mounting bracket		6.20
A-5334	Silver contact washer	83	.28
A-5335	Silver contact point for A-5334	83	.18
A-5341	Vibration damper for coin chute switch	70, 77	1.00
A-5362	Vibration damper and coin chute switch	70, 77	2.20
B-5363	Relay switch assembly	56	.80
B-5364	Relay switch assembly	56	.76
B-5365	Relay switch assembly	56	.86
B-5366	Relay switch assembly	56	.76
B-5367	Relay switch assembly	56	.86
B-5368	Relay switch assembly	56	.98
A-5369	"AG" relay armature and insulator arm	56	.68
A-5370	"AG" relay armature and insulator arm	56	.74
A-5536	.010" Formed switch blade	57	.18
	.010" Formed switch blade with A-2040 point34
A-5569	Metal shield, 4-1/2" centers58
A-5662	Coil		1.90
A-5673	Contact kicker coil and bracket		4.60
A-5723	Hole kicker coil		2.30
A-5743	Connector insulator08
A-5867	Hole guard44
A-5891	Hole guard44
A-5977	Ball guide rail42
D-6038	Back "U" trim		4.00
D-6039	Playboard glass stop trim		4.00
B-6046	Right hand insert lock lever	29	1.62
B-6047	Left hand insert lock lever	29	1.62
A-6049	Shipping block56
A-6087	Plastic slip in core 1-31/32"	81	.26
A-6088	Coil		2.64
B-6183	Transformer		39.00
A-6338	Metal shield 5-3/4" centers90
A-6500	Metal shield 6" centers90
A-6513	Allen head "T" wrench	85	5.10
A-6612	Ball guide rail34
A-6615	Metal light shade80
A-6616	Light shade bracket		1.62
A-6617	Roto unit metal shield		1.08
A-6698	Coil		2.40
A-6791	Flat rail68
A-6888	Flipper shaft and shoe assembly	13	.84
A-6931	Ball guide rail24
A-6941	Unit mounting bracket	37	.46
A-6942	Unit mounting bracket	37	.46
A-6943	Unit mounting bracket	37	.46
A-6944	Unit mounting bracket	37	.46
A-6945	Unit mounting bracket	37	.54
A-6947	Hairpin fastener	37	.08
A-6981	Swinging target switch rod	20	.18

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-7003	Spring	30, 31, 32, 33, 34, 40	.16
A-7032	3/64" I.D. x 1/4" O.D. nylon washer	20	.06
A-7049	Cash box lock eye42
A-7181	Front door hinge nut strip	66	.58
A-7186	Front door lock bolt	68	.58
A-7187	Front door lock bolt guide	68	.58
A-7189	Front door lock cam	68	.82
B-7192	Front door coin guide trough	66	3.80
B-7193	Front door coin return housing	65	2.00
B-7194	Front door coin return cover	65	1.20
B-7196	Front door hinge	66	1.80
D-7211	Front door - double chute	65	18.00
D-7212	Front door		18.00
D-7213	Front door - single chute	65	18.00
A-7214	Cash box divider for D-7216 cash box64
C-7215	Cash box cover for D-7216 cash box		2.30
D-7216	Cash box		6.00
A-7291	Wiper finger .045" thick	37	.14
A-7292	Wiper finger bushing for A-7291	37	.14
A-7408	Lockdown adjustment screw	28	.14
A-7478	Front door hole plug	66	.44
A-7495	Front door coin return baffle plate	66	.30
A-7581	Penny rebound strip10
A-7593	Solder lug blade	82	.12
B-7618	Wiper		3.84
A-7652	Plunger	80	.96
A-7677	Coil	67	2.40
A-7704	Bayonet socket32
A-7746	Bayonet socket32
B-7760	Motor (1/4" shaft)	62	16.50
A-7766	Motor cam assembly		5.20
A-7769	Actuating arm spring	53	.06
A-7800	Bank setup coil	81	3.20
A-7827	Armature spring	53	.08
A-7876	Series bar, 1 position	55	1.84
A-7877	Series bar, 3 position	55	1.98
A-7878	Series bar, 4 position	55	2.10
A-7879	Series bar, 5 position	55	2.20
A-7881	Series bar, 6 position	55	2.28
A-7896	Series bar, 1 position	55	1.92
A-7897	Series bar, 3 position	55	2.06
A-7907	Motor cam assembly		6.30
B-7986	Transformer		72.00
A-8083	Motor cam assembly		5.40
B-8089	Front door strike plate	67	2.54
B-8091	Transformer		46.00
A-8107	Formed backing switch blade	82	.20
A-8111	Plastic Slip-in core	47, 49, 81	.22
D-8158	Pedestal		4.60
D-8159	Stainless moulding left side		15.00
A-8215	Metal shield (runway)	24	.46

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-8230	Nylon drive lever bearing	36	.22
B-8246	Pop bumper trim platter	2, 3, 5	.14
B-8263	Switch assembly 2A, 1B, motor	61	2.30
B-8264	Switch assembly 2A, 1B, motor	61	2.54
B-8265	Switch assembly 2A, 1B, motor	61	2.80
B-8269	Switch assembly 1A, motor	61	.86
B-8270	Switch assembly 1A, motor	61	1.12
B-8271	Switch assembly 2A, motor	61	1.68
B-8272	Switch assembly 3A, motor	61	2.34
B-8273	Switch assembly 3B, motor	61	2.34
B-8274	Switch assembly 2B, motor	61	1.72
B-8275	Switch assembly 1A, 1B, motor	61	1.72
B-8276	Switch assembly 1B, motor	61	1.10
B-8277	Switch assembly 1A, 2B, motor	61	2.36
B-8278	Switch assembly 1A, 2B, motor	61	2.34
B-8279	Switch assembly 1A, 3B, motor	61	2.94
B-8280	Switch assembly 1A, 4B, motor	61	3.54
B-8281	Switch assembly 1A, 5B, motor	61	4.50
B-8286	Switch assembly 1A, motor	61	.88
B-8287	Switch assembly 2A, motor	61	1.70
B-8288	Switch assembly 3A, motor	61	2.36
B-8293	Switch assembly 1B, motor	61	.92
B-8294	Switch assembly 3B, motor	61	2.36
B-8295	Switch assembly 2B, motor	61	1.72
B-8296	Switch assembly 2B, 1A, motor	61	2.32
B-8297	Switch assembly 1A, 1B, motor	61	1.48
B-8298	Switch assembly 1B, motor	61	.86
B-8299	Switch assembly 2B, motor	61	1.46
B-8300	Switch assembly 3B, motor	61	2.14
B-8301	Switch assembly 4B, motor	61	2.96
B-8302	Switch assembly 4B, motor	61	3.44
B-8303	Switch assembly 5B, motor	61	3.64
B-8304	Switch assembly 3A, 3B, motor	61	4.70
B-8305	Switch assembly 2A, 2B, motor	61	3.18
B-8306	Switch assembly "brake", motor	63	.46
A-8307	Drive lever	30, 31, 32, 33, 34, 36	2.78
B-8309	Switch assembly 2B, 1A, motor	61	2.36
A-8311	Drive lever	40, 41	3.12
B-8312	Switch assembly 2B, motor	61	1.76
B-8321	Switch assembly 4B, motor	61	3.70
B-8326	Switch assembly 1B, motor	61	.90
B-8328	Switch assembly 1A, 2B, motor	61	2.60
B-8329	Switch assembly 2A, 2B, motor	61	3.38
B-8330	Switch assembly 1A, 2B, motor	61	2.86
B-8343	Switch assembly 1A, motor	61	1.14
B-8372	Switch assembly 1B, bounce switch	84	1.14
B-8373	Switch assembly 1A, playboard tilt switch	84	1.14
B-8374	Switch assembly 1B, shutoff switch90
B-8375	Switch assembly 1B, anti-cheat switch (door)	70	1.06
B-8377	Switch assembly 1A, 1B, push button, anti-cheat	70	1.96
B-8379	Switch assembly 1A, 4B, motor	61	4.60

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-8384	Switch assembly 1A, 4B, motor	61	4.10
B-8385	Switch assembly 2A, 2B, motor	61	2.94
B-8386	Switch assembly 2A, 4B, motor	61	4.60
B-8387	Switch assembly 2A, 4B, motor	61	4.50
B-8388	Switch assembly 1A, 3B, motor	61	3.70
B-8389	Switch assembly 1A, 1B, motor	61	1.66
B-8391	Switch assembly 3A, 1B, motor	61	3.20
B-8393	Switch assembly 1B, 1A, motor	61	1.98
B-8394	Switch assembly 1A, 3B, motor	61	3.42
B-8448	Switch assembly 1A, bank	54	.82
B-8449	Switch assembly 2A, bank	54	1.46
B-8450	Switch assembly 1B, bank	54	.82
B-8451	Switch assembly 2B, bank	54	1.46
B-8452	Switch assembly 1C, 1A, bank	54	1.90
B-8453	Switch assembly 1C, 1A, bank	54	1.92
B-8454	Switch assembly 1C, bank	54	1.08
B-8455	Switch assembly 1C, 1B, bank	54	1.90
B-8456	Switch assembly 1B, 1A, bank	54	1.46
B-8457	Switch assembly 1B, bank	54	1.18
B-8458	Switch sub assembly 1A, bank	54	.90
B-8459	Switch sub assembly 1B, bank	54	.90
B-8460	Switch sub assembly 1C, bank	54	1.10
B-8461	Switch sub assembly 1A, bank	54	.88
B-8462	Switch assembly 1C, bank	54	1.10
B-8463	Switch sub assembly 2B, bank	54	1.62
B-8464	Switch assembly 2A, bank	54	1.46
A-8476	Reset lever	36	1.14
A-8514	Ball guide rail34
B-8519	Switch assembly 3B, replay unit, "O" pos.	38	2.80
B-8520	Switch assembly 1A, 1B, replay unit, drive arm	38	1.96
B-8521	Switch assembly 1B, replay unit, drive arm	38	1.00
B-8522	Switch assembly 1A, replay unit, drive arm	38	1.30
B-8525	Switch assembly 1B, 30 point step sw., "O" pos.	39	1.06
B-8526	Switch assembly 1A, 1B, 30 point step sw., "O" pos.	39	1.64
B-8527	Switch assembly 1A, 2B, 30 point step sw., "O" pos.	39	2.62
B-8528	Switch assembly 1B, kicking rubber	10	.84
B-8531	Switch assembly 1A, hole kicker	8	.82
B-8532	Switch assembly 2A, hole kicker	8	1.46
B-8533	Switch assembly 1A, rollover & contacts	23	.90
B-8534	Switch assembly 1A, 1B, rollover & contacts	23	1.64
B-8535	Switch assembly 2A, rollover & contacts	23	1.64
B-8552	Switch assembly, with bracket (bumper)	4, 5	1.32
B-8555	Switch assembly, with bracket (flipper)	12	1.64
A-8560	Strike plate (lightbox)	29	.32
C-8561	Lightbox door channel - small	29	1.08
C-8562	Lightbox door channel	29	1.10
D-8563	Metal lightbox door	29	10.00
D-8564	Metal lightbox door	29	11.50
A-8571	Stop bracket	2, 3	.26
A-8578	Metal shield 5-3/4" centers68

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-8606	Switch assembly 4A, motor	61	3.48
D-8624	Lightbox	29	72.00
D-8627	Lightbox	29	84.00
B-8654	Switch assembly 1A, 3B, motor	61	3.46
B-8656	Switch assembly 1B, 2A, motor	61	2.60
B-8657	Switch assembly 2A, motor	61	1.94
B-8659	Transformer		72.00
B-8660	Transformer		42.00
B-8675	Switch assembly 3A, 2B, motor	61	4.20
B-8678	Motor cam assembly		5.10
A-8688	Flat rail90
A-8689	Playboard prop stick		2.54
A-8690	Spring	75	.10
A-8695	Hole kicker cam (with spring)		2.54
B-8703	Switch assembly 1A, with bracket, bumper	5	1.32
B-8707	Switch assembly 1A, swinging target	20	1.04
B-8708	Switch assembly 1A, 1B, rollunder	20	1.52
B-8709	Switch assembly 1A, rollunder	20	.88
B-8713	Switch assembly 2A, bank	56	1.46
A-8727	Spring	8, 9	.14
A-8737	"AS" relay armature spring	58	.16
A-8738	"AS" relay armature override stop	58	.26
A-8740	"AS" relay ratchet flat spring	58	.26
A-8741	"AS" relay formed switch blade	59	.20
A-8742	"AS" relay wiper retainer42
C-8749	"AS" relay coil frame	59	1.04
C-8750	"AS" relay armature frame	58	.76
C-8752	Nylon cam 10 point, "AS" relay	58	.54
C-8753	Nylon cam 2 point B, "AS" relay	58	.30
C-8754	Nylon cam 2 point A, "AS" relay	58	.30
D-8755	Nylon ratchet spindle, "AS" relay	58	.58
B-8778	Reset arm, 1 coil, 5 pos.	52	6.10
B-8779	Reset arm, 1 coil, 6 pos.	52	6.40
B-8780	Reset arm, 1 coil, 7 pos.	52	6.80
B-8781	Reset arm, 1 coil, 8 pos.	52	7.10
B-8782	Reset arm, 1 coil, 9 pos.	52	7.50
B-8783	Reset arm, 1 coil, 10 pos.	52	7.90
B-8784	Reset arm, 1 coil, 11 pos.	52	8.30
B-8785	Reset arm, 1 coil, 12 pos.	52	8.70
B-8786	Reset arm, 2 coil, 13 pos.	52	9.90
B-8787	Reset arm, 2 coil, 14 pos.	52	10.50
C-8799	Reset coil mounting bracket	52	1.04
C-8800	Reset coil mounting bracket	52	1.04
B-8808	Switch assembly 3B, motor	61	2.62
A-8829	Plunger housing plate	26	.26
A-8831	Trim plate	26	1.28
A-8833	Plunger shaft & knob	26	2.64
B-8834	Nylon plunger housing	26	.54
B-8835	Ball shooter plunger assembly	26	6.40
A-8845	3/4" dia. playboard insert (specify color)16
A-8846	7/8" dia. playboard insert (specify color)18

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-8847	1" dia. playboard insert (specify color)20
A-8848	1-3/16" dia. playboard insert (specify color)22
B-8849	Switch assembly 2A, 4B, motor	61	4.70
B-8850	Switch assembly 1A, 4B, motor	61	4.70
B-8851	Switch assembly 1B, 2A, motor	61	2.34
A-8857	Post fastening screw	24	.24
A-8903	Ball guide rail (wireform)42
A-8930	Metal shield 3-7/8" centers58
B-8931	Switch assembly 2B, motor	61	2.00
A-8933	Disc (see A-9016)		
A-8934	Disc (see A-9017)		
B-8937	Switch assembly 4B, motor	61	3.20
C-8966	Wiper		8.70
A-8972	Flat rail92
B-8998	Switch assembly 1A, 1B, motor	61	1.66
A-9012	"AS" relay ratchet & 10 point cam	58	1.18
A-9013	"AS" relay ratchet 2 point "A" & "B" Cam . . .	58	1.64
A-9014	"AS" relay armature (replaced by A-14044) . . .	58	
A-9015	"AS" relay wiper	59	.38
A-9016	"AS" relay disc	59	1.74
A-9017	"AS" relay disc	59	1.74
B-9018	Switch assembly 1A, "AS" relay	59	.90
B-9019	Switch assembly, with bracket, flipper	12	1.54
B-9023	Switch assembly 1A, motor	61	.88
B-9031	Switch assembly 1A, 2B, motor	61	2.36
A-9032	Armature & lifter	53	.54
B-9056	Switch assembly, flipper		1.06
B-9057	Switch assembly with bracket, flipper	12	1.52
B-9059	Switch assembly with bracket, flipper	12	1.54
B-9078	Bayonet sockets & strip (7 sockets 1-1/2" centers)		2.32
B-9100	Switch assembly 2A, 3B, motor	61	3.78
B-9101	Switch assembly 3A, 2B, motor	61	3.86
B-9103	Replay unit guard		1.28
A-9105	Armature & rivet	53	.42
B-9135	Switch assembly 1A, slug rejector chute	70	.80
B-9141	Switch assembly, with bracket, tilt	84	1.48
A-9143	Rebound rubber & bracket	25	1.04
B-9144	Switch assembly 1A, 4B, motor	61	4.40
B-9146	Switch assembly 2A, 4B, motor	61	5.20
A-9150	Metal shield58
A-9151	Spring, drive rack	47, 49	.12
A-9152	Spring, switch lever	47	.10
A-9153	Spring, drive spool	47, 49	.08
A-9154	Coil	47, 81	1.92
A-9158	Index flat spring	47, 49	.36
A-9159	Drive spool bearing	47	.18
B-9166	Wiper	47, 49	.58
C-9167	Thrust bearing	47, 49	.20
C-9170	Frame	47	5.20
D-9172	Drive spool	47, 49	.22
B-9188	Bayonet socket strip (10 sockets)		3.10

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-9191	Wiper		2.44
C-9194	Disc		9.90
B-9209	Bayonet sockets & strips, 6 sockets		1.86
A-9224	Hole kicker coil & bracket	7	4.50
A-9272	Spring, armature	58	.16
A-9273	Metal shield, 4-5/8" centers70
B-9292	Reset arm, 13 pos. single coil		9.10
A-9323	Insulated cable retainer20
B-9328	Switch assembly, runway	23	.88
A-9329	Motor cam assembly	63	5.80
B-9348	Motor frame		11.00
A-9349	Formed switch blade	63	.20
A-9372	Metal shield, 5-5/8" to 6" centers80
A-9374	Plastic target (specify color)	22	.26
A-9383	Plastic target, bullseye	22	.36
A-9384	Switch assembly 2A, 3B, motor	61	4.10
B-9385	Switch assembly 3B, motor	61	2.38
B-9391	Switch assembly 4B, motor	61	3.44
A-9393	Plastic guide rail, 1-1/2" centers, single apron20
A-9394	Plastic guide rail, 1-1/2" centers, double apron22
A-9395	Plastic guide rail, 2-1/8" centers, single apron22
A-9396	Plastic guide rail, 2-1/8" centers, double apron22
A-9397	Plastic guide rail, 2-1/2" centers, single apron22
A-9398	Plastic guide rail, 2-1/2" centers, double apron24
A-9414	Pop bumper trim platter — cutoff16
A-9460	Point file (diamond dust)	85	21.50
B-9476	Switch assembly 1A, 1B, motor	54	1.72
A-9478	Ball guide rail44
A-9479	Coil	81	4.60
A-9500	Metal flat rail58
A-9511	Bayonet socket strip (6 sockets)		2.20
A-9517	5" bell mounting bracket	80	.36
A-9518	Bell coil mounting bracket	80	.70
A-9519	Relay clip	56, 60	.18
A-9520	Brass coil stop, collar & nut replaced by A-4862		
A-9538	Silver contact point	83	.26
A-9574	Switch blade, dual point, lifter42
A-9575	Switch blade, bifurcated42
B-9576	Switch assembly 2A, 1B, score	45	2.68
B-9577	Switch assembly 3A, score	45, 47	2.72
A-9578	Bell coil & mounting bracket assembly	80	5.50
B-9579	5" bell assembly	80	8.60
B-9584	Switch assembly 2A, 1B, motor	64	2.22
A-9587	Nylon washer 1/4" I.D.	46	.06
A-9589	Target blade & point	22	.42
A-9590	Plastic target & blade (specify color)70
B-9591	Target & switch assembly, 1A (specify color)	22	2.20
B-9592	Target & switch assembly, 2A (specify color)	22	2.88
B-9593	Switch assembly 1C, 2B, replay	39	2.50
A-9619	Ball kicker cam		1.74
A-9668	Switch lever	47	.36
A-9669	Drive rack	47	1.74

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-9711	Wiper mounting spider	37	.46
C-9721	Bayonet socket strip (10 sockets)		2.76
A-9733	Coil		2.10
A-9735	Coil		2.20
A-9736	Coil	75	2.30
A-9738	Coil		2.10
A-9740	Coil	18	2.30
A-9741	Coil		3.50
A-9742	Coil		2.00
A-9746	Coil		2.20
B-9747	Switch assembly 2A, 3B, motor	61	4.30
B-9748	Switch assembly 3A, 3B, motor	61	4.90
B-9752	Switch assembly 2B, 1C, motor	61	2.66
B-9753	Switch assembly 1A, 1C, motor	61	2.02
B-9754	Switch assembly 5B, motor	61	4.20
B-9755	Switch assembly 1A, 5B, motor	61	5.00
A-9757	Rollover wireform & bracket	23	.74
A-9758	Spring	7, 8, 9	.14
A-9759	Arch fastening bracket20
A-9760	Arch clip18
B-9762	Ball return track	25	.82
B-9763	Ball return fence	25	1.04
C-9764	Ball return fence	25	1.52
C-9767	Ball shooter gauge	25	1.98
A-9821	Metal shield 5-3/8" to 5-3/4" centers78
B-9886	Switch assembly 3A, 2B, motor	61	3.62
B-9892	Target & switch assembly, 1A (specify color)		2.20
A-9933	Arch stick protector	25	.46
B-9982	Switch assembly 1C, 1A, bank	8	1.76
A-9988	Hole kicker cam		1.86
A-9996	Hole kicker coil assembly		4.10
B-9998	Wiper		7.00
B-10045	Switch assembly 1B, 1A, motor	61	1.72
A-10051	Lockdown adjusting nut20
A-10052	Lockdown adjusting screw18
D-10054	Lockdown moulding assembly replaced by D-14008		
A-10060	Front door lock strike plate	68	.40
B-10064	Coin return cover	65	1.40
D-10066	Front door, triple chute	65	18.00
B-10101	Target & switch assembly 1A, (specify color)		2.20
A-10103	Motor mounting bracket	63	.46
B-10104	Motor mounting bracket	63	.68
A-10108	Hole kicker cam	8	2.32
A-10126	Kicker coil & bracket assembly	8	4.60
A-10131	Metal shield 5" centers68
B-10150	Switch assembly 1C, 30 point step switch	39	1.06
A-10164	Shock mount36
A-10165	Shock mount kit, replay kit70
B-10215	Switch assembly 1B, 2A, motor	61	2.60
A-10216	Kicker coil & bracket assembly		5.90

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-10217	Rubber ring 5/16" I.D. (#1)08
A-10218	Rubber ring 3/4" I.D. (#2)08
A-10219	Rubber ring 1" I.D. (#10)	4	.10
A-10220	Rubber ring 1-1/2" I.D. (#11)12
A-10221	Rubber ring 2" I.D. (#12)14
A-10222	Rubber ring 2-1/2" I.D. (#14)16
A-10223	Rubber ring 3" I.D. (#16)20
A-10224	Rubber ring 3-1/2" I.D. (#18)22
A-10225	Rubber ring 4" I.D. (#20)30
A-10226	Rubber ring 5" I.D. (#25)52
A-10234	Pop bumper trim platter, cutoff12
A-10271	Adjustable zero stop	32	.30
A-10275	Gear & shaft		3.24
A-10276	Gear & shaft	33	3.24
B-10277	Wiper arm, 3 row span, 12 holes	35	.68
B-10278	Wiper arm, 3 row span, 6 holes	35	.68
B-10279	Wiper arm, 5 row span, 20 holes	35	.76
B-10280	Wiper arm, 5 row span, 10 holes	35	.76
A-10285	Wiper cover plate	37	.36
B-10288	Frame	34	10.50
C-10289	Replay wheel (0-15)	34	2.32
A-10293	Gear & shaft		3.34
B-10296	Switch assembly 2B, 30 point step switch	38	1.88
B-10297	Switch assembly 5B, motor	61	3.88
A-10303	Light shade06
A-10335	Tilt bob wire, use only with A-730 clip20
C-10336	Ball roll tilt housing	84	2.20
B-10337	Switch assembly, ball roll tilt92
C-10356	Nylon cam, 5 points	58	.36
B-10378	Relay clip, "AS" relay	59	.42
C-10424	Playboard support, left		2.32
C-10425	Playboard support, right		2.32
B-10428	Switch assembly 1A, 1B, score	45	2.10
A-10430	Spring, bumper	3, 5	.04
B-10431	Bumper adaptor ring	4	.24
B-10432	Bumper base	2, 3, 4	.20
C-10433	Bumper skirt	2, 3, 4	.34
C-10434	Bumper cap (no printing)34
A-10436	Pop bumper body, diamond design	2, 3, 6	.84
B-10439	Bayonet socket strip (10 sockets)		3.66
A-10441	Plastic target & blade (specify color)70
B-10475	Switch assembly 3A, 1B, motor	61	3.20
B-10524	Switch assembly 2A, 30 point step switch	38	2.00
B-10525	Switch assembly 1B, motor	61	1.10
A-10542	Steel pin	24	.06
A-10547	Gear & shaft	34	3.34
B-10557	Switch assembly 3A, 3B, motor	61	4.80
A-10573	Bayonet socket22
A-10575	Bayonet socket strip (6 sockets)		1.96
B-10587	Switch assembly 1A, 30 point step switch	38	1.00
A-10617	Cam link, 1-1/2" centers36

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-10623	Switch assembly 1C, 1B, motor	61	1.80
A-10633	Contact kicker		1.46
B-10668	Switch assembly 3B, replay	38	2.56
B-10672	Switch assembly 1A, roto	40	1.64
A-10692	Flat rail54
A-10703	Spring washer	47	.02
A-10704	Bayonet socket34
B-10707	Coin feed trough	69	1.46
B-10708	Coin trough cover	69	1.46
B-10709	Coin trough cover, 25¢	69	1.50
C-10710	Coin entrance plate (no opening)	71	.68
C-10711	Coin entrance plate	71	.68
C-10712	Coin entrance plate	71	.68
C-10713	Coin entrance plate	71	.68
C-10714	Coin entrance plate	71	.68
C-10715	Coin entrance plate	71	.68
C-10716	Coin entrance plate	71	.68
C-10717	Coin entrance plate	71	.68
C-10718	Coin entrance housing	69	3.46
C-10719	Coin entrance housing	69	3.46
C-10720	Coin entrance housing	69	3.46
C-10722	Coin entrance mounting plate	69	2.64
A-10723	5¢ - 1 play, illuminated label	71	.36
A-10724	2 nickels - 1 play, illuminated label	71	.36
A-10725	10¢ - 1 play, illuminated label	71	.36
A-10726	10¢ - 2 plays, illuminated label	71	.36
A-10727	25¢ - 2 plays, illuminated label	71	.36
A-10728	25¢ - 3 plays, illuminated label	71	.36
A-10729	25¢ - 4 plays, illuminated label	71	.36
A-10730	25¢ - 5 plays, illuminated label	71	.36
B-10737	Switch assembly type 7, 2C, AG relay	56	1.98
B-10740	Switch assembly 3B, 30 point step switch	39	2.36
D-10744	Cabinet, triple chute, less trim		170.00
D-10798	Cabinet, single chute, less trim		170.00
B-10799	Switch assembly 1A, motor	61	1.14
B-10800	Switch assembly 3A, motor	61	2.60
A-10802	Spring12
C-10808	Unit mounting lock slide	50, 51	.26
B-10809	Unit mounting lock slide	50, 51	.24
D-10813	Lightbox metal door	29	13.50
B-10815	Switch assembly 3A, 1B, motor	61	3.20
B-10816	Switch assembly 1A, 1C, 30 point step switch	39	1.70
D-10824	Lightbox assembly	29	85.00
A-10834	Yellow blank, illuminated label40
A-10835	Red blank, illuminated label36
A-10848	Ratchet & 5 point cam	58	.94
B-10851	Switch assembly 2A, score	45	2.16
B-10857	Switch assembly 1A, 5B, motor	61	4.70
B-10858	Switch assembly 2A, 3B, motor	61	4.30
B-10883	Switch assembly 1A, 30 point step switch	39	.80
A-10935	Bottom arch light hole cover36

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-10936	Bottom arch light shield24
A-10941	Metal shield 5-7/8" to 6-1/4" centers78
A-10945	Hole kicker cam, with spring	7	3.36
A-10949	Toggle switch plate36
B-10957	Switch assembly 2A, "AS" relay	59	1.68
B-10958	4 position shelf assembly, bottom	46	7.00
B-10959	4 position shelf assembly, top	46	7.00
B-10996	Switch assembly 2B, 30 point step switch	39	1.64
A-10998	Bumper cap "10 points when lit"	6	.36
A-11003	Flat rail68
A-11007	Metal shield 5-1/4" centers78
A-11008	Flat rail78
C-11021	Coin entrance mounting plate	69	3.46
C-11022	Coin entrance mounting plate	69	3.46
B-11033	Switch assembly 1C, 1A, 30 point step switch	39	1.76
B-11034	Switch assembly 1A, 1B, replay	38	1.72
B-11040	Switch assembly 1A, 3B, 1C, motor	61	4.10
A-11051	Plunger & collar	47	.56
C-11052	Drive rack insert18
A-11058	Coil		2.90
C-11059	Cashbox liner, small		1.38
C-11060	Cashbox liner, large		1.82
A-11061	Bumper cap, "100 points"36
A-11071	Flat rail82
A-11076	Formed switch blade	7	.18
B-11077	Switch assembly 1A, ball return	7	.96
A-11094	Plastic target, specify color	22	.36
A-11113	Metal shield78
B-11134	Switch assembly 2C, bank	56	1.88
A-11145	Coin entrance plate, 2 x 25 ore, 1 play	72	1.04
A-11146	Coin entrance plate, 1 krona, 3 plays	72	1.04
C-11148	Coin entrance housing		3.46
C-11149	Coin entrance housing		3.46
A-11150	Flat rail58
A-11151	Hole liner	8	.20
B-11157	Switch assembly 3B, 1A, motor	61	3.10
A-11158	Pop bumper trim platter - cutoff14
A-11159	Coin entrance plate, 25 centimos, 1 play	72	1.04
B-11186	Coin feed trough cover		1.40
B-11187	Coin feed trough	69	1.46
B-11188	Coin feed trough cover	69	1.46
A-11189	Metal shield - 6-1/2" centers82
A-11215	Cam link 2-3/4" centers42
B-11219	Switch assembly 2A, 1B, 30 point step switch	39	2.52
A-11240	Coin entrance plate, 2 shillings - 4 plays	72	1.04
C-11241	Plastic flipper (blank)	13	.32
A-11246	Coin entrance plate, 2 x 1 peseta - 1 play	72	1.04
A-11247	Coin entrance plate, 5 pesetas - 3 plays	72	1.04
B-11271	Bayonet sockets & strip, 6 on 2-1/8" centers		1.88
A-11278	Bumper cap "changes indicated value"	6	.36
D-11279	Radius arch plate track, plated		5.40
A-11283	Gear & shaft		3.34

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-11305	Bumper cap "10 points"36
A-11313	Coin entrance plate, 5 francs	72	1.04
A-11316	Rollover wire assembly64
A-11321	Coin entrance plate, 50 centimes — 2 plays		1.04
A-11322	Coin entrance plate, 1 franc — 5 plays	72	1.04
A-11335	Coin entrance plate, 25 kurus — 1 play	72	1.04
A-11336	Coin entrance plate, 1 lira — 2 plays	72	1.04
A-11337	Coin entrance plate, 5 cents — 1 play		1.04
A-11338	Coin entrance plate, 10 cents — 2 plays	72	1.04
A-11339	Coin entrance plate, 20 cents — 4 plays	72	1.04
A-11345	Front rest saddle	26	.46
A-11346	Front rest hook	26	.36
A-11347	Anti-lift bracket	26	.36
A-11348	Anti-lift shoulder pin	26	.62
D-11352	Lockdown moulding slide	28	11.00
B-11353	Switch assembly 1A, 2B, 30 point step switch	39	2.14
A-11372	Coin entrance plate, 25 francs — 1 play	72	1.04
A-11389	Coin entrance plate, 1 krone — 3 plays	72	1.04
A-11393	Coin entrance plate, 2 x 25 ore — 1 play		1.04
A-11394	Coin entrance plate, 2 nickels — 1 play	72	1.04
A-11395	Coin entrance plate, 10¢ — 1 play	72	1.04
A-11396	Coin entrance plate, 25¢ — 3 plays	72	1.04
A-11423	Bumper cap "10 points"	6	.36
A-11424	Bumper cap "10 points when lit"	6	.36
A-11425	Bumper cap "100 points"	6	.36
A-11426	Bumper cap "100 points when lit"	6	.36
B-11428	Switch assembly 4B, motor	61	3.68
B-11431	Switch assembly 3B, motor	61	2.88
B-11434	Switch assembly 1A, 3B, motor	61	2.96
B-11435	Switch assembly 1A, 1C, motor	61	1.80
C-11444	Electric ball shooter kit	86	8.50
A-11446	Coin return door	66	.86
A-11450	Disc		3.82
A-11451	Disc		3.82
C-11466	Nylon-shaft bearing replaced by D-16274		
B-11467	Switch assembly, 1C, "AS" relay	59	1.14
A-11471	Coin entrance plate, 5¢	72	1.04
A-11472	Coin entrance plate, 10¢	72	1.04
A-11473	Coin entrance plate, 25¢		1.04
A-11478	15¢ — 1 play, 25¢ — 2 plays, label36
A-11524	Coin entrance plate, 20 centimes — 1 play		1.04
A-11525	Coin entrance plate, 50 centimes — 3 plays		1.04
A-11527	Shoulder screw	18	.82
A-11530	Disc		1.56
B-11534	Target arm		1.16
B-11535	Target arm & cam	18	2.48
C-11536	Frame	18	2.34
A-11537	Formed switch blade18
B-11538	Switch assembly, vari-target	18	.82
B-11539	Switch assembly 1A, vari-target	18	.82
B-11541	Frame		5.20

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-11542	Switch assembly 1B, 30 point step switch	39	.80
A-11543	Ball guide rail44
A-11544	Ball guide rail62
B-11545	Ball guide rail62
B-11550	Motor 50 Hz.	62	16.50
A-11552	Bayonet sockets & strip, (5)	51	1.56
A-11556	Circuit delay module	64	4.40
C-11561	Plastic post 1" high (white)	24	.14
C-11562	Plastic post 1-3/16" high (white)	24	.16
A-11573	Coin entrance plate, 2 shillings — 5 plays	72	1.04
C-11576	Bayonet sockets & strips (5)		2.20
B-11578	Switch assembly 2A, 1B, motor	61	2.60
A-11579	Coin entrance plate, 1 sixpence — 1 play		1.04
A-11603	Formed switch blade18
A-11611	Flipper & shaft assembly	13	1.30
A-11637	Lockout mounting bracket	67, 79	.36
A-11638	Tie bar — 8-1/8"	67, 79	.70
A-11639	Armature	67, 79	.22
A-11640	Lockout wireform	67, 79	.18
A-11641	Actuating rod — 2-1/4"	67, 79	.18
B-11642	Actuating rod — 8-5/8"	67	.46
A-11648	Gear & shaft		3.74
A-11650	Gear & shaft		3.74
A-11652	Gear & shaft		3.74
A-11654	Gear & shaft		3.74
A-11669	Gear & shaft		3.98
B-11670	Frame		7.90
B-11671	Frame	33	7.00
B-11675	Switch sub-assembly 1A, 1B, bank	54	1.56
A-11703	Ball guide rail42
B-11777	Switch assembly 2A, motor	61	1.96
B-11788	Wiper retainer, "AS" relay	59	.46
C-11825	Lightbox door channel		1.26
A-11826	Bumper cap "1000 points when lit"	6	.36
B-11852	Switch assembly 1A, 2B, 30 point step switch	39	2.14
B-11853	Target & switch assembly (specify color)		2.20
A-11886	Coin entrance plate, 25¢ — 2 plays	72	1.04
B-11895	Switch assembly 5B, motor	61	3.88
B-11901	Switch assembly 1A, 4B, 1C, motor	61	4.40
B-11902	Switch assembly 2B, 30 point step switch	39	2.14
B-11905	Target arm, blank — specify color42
D-11966	Rollover insert	23	.42
D-11968	Rollover button	23	.26
A-11973	Coin entrance plate, 2 x 25 ore — 1 spel	72	1.04
A-11974	Coin entrance plate, 1 pollett — 1 spel		1.04
A-11975	Coin entrance plate, 1 krona — 3 spel	72	1.04
B-11997	Switch assembly 1A, motor	61	.92
B-11998	Switch assembly 1A, motor	61	1.18
B-11999	Switch assembly 2A, motor	61	1.68
B-12000	Switch assembly 2A, motor	61	1.92
B-12001	Switch assembly 2A, motor	61	2.18

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-12002	Switch assembly 3A, motor	61	2.28
B-12003	Switch assembly 3A, motor	61	2.54
B-12004	Switch assembly 3A, motor	61	2.78
B-12012	Switch assembly 3B, 30 point step switch	39	2.20
A-10215	Tone box	80	1.40
A-12016	Tone bar (low note)	80	1.80
A-12017	Tone bar (middle note)	80	1.74
A-12018	Tone bar (high note)	80	1.64
C-12019	Coil mounting bracket	80	.98
B-12021	Frame	80	3.04
B-12022	Sub-assembly coils & mounting bracket		16.00
B-12023	Assembly of chime	80	28.00
A-12037	Coin entrance plate, 10 francs	72	1.04
A-12047	Flipper coil link, 2-1/4" centers	13	.32
A-12051	Flipper lever arm	13	2.76
A-12052	Flipper lever arm	13	2.76
A-12053	Flipper arm, link & plunger assembly		4.70
A-12054	Flipper arm, link & plunger assembly		4.70
A-12091	Coin entrance plate, pollet		1.04
A-12092	Coil — replaced by A-5195		
A-12106	Ball guide rail		.46
A-12107	Ball guide rail		.46
B-12109	Frame		7.80
A-12110	Motor cam assembly		5.20
A-12127	Flat rail		.46
A-12144	Spring	18	.18
A-12145	Formed switch blade		.16
A-12146	Coil mounting bracket	18	.16
A-12149	Slotted yoke	2, 3, 5	.20
A-12154	Coin entrance plate, 2 x 50 pennia — 1 play	72	1.04
A-12155	Coin entrance plate, 1 markka — 2 plays	72	1.04
A-12172	Contact pin	53	.08
A-12173	Contact pin insulator	53	.04
A-12178	Spring	15, 16, 17	.06
A-12179	Trigger shaft 13-1/2" long	16	1.10
A-12180	Mounting leg	15, 16	.22
A-12181	Trigger	15, 16	.10
B-12183	Reset arm assembly (10 pos.)	15	4.40
C-12184	Coil setup bracket	15	.64
C-12185	Coil setup bracket	15	.64
D-12186	Pivot plate	16	2.32
D-12187	Switch plate	16	2.40
D-12188	Guide plate	15, 16	1.78
B-12190	Switch assembly 1A, 1C, bank	54	1.72
A-12290	Plastic target circles (specify color)	22	.36
B-12295	Switch assembly 3A, motor	61	3.02
B-12298	Switch assembly 1A, 1C, bank	54	1.72
A-12301	Plastic target, octagons (specify color)	22	.36
A-12324	Actuating arm assembly (1 pin)	53	.76
A-12326	Actuating arm assembly (2 pins)	53	1.00
C-12344	Cam follower	30, 31	.16

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-12399	Gear & shaft	30	3.12
A-12400	Switch mounting bracket	30	.38
C-12403	Frame	30, 31	3.00
C-12404	Frame extension	30	1.62
C-12405	Switch cam, 5 lobes — white	30	.22
C-12406	Switch cam, 1 lobe — black	30	.26
B-12408	Switch assembly, 1A, 1B, 30 point step switch . .	39	1.46
A-12415	Coin entrance plate, 20 pennia — 1 play	72	1.04
A-12417	Coin entrance plate, 50 pennia — 3 plays	72	1.04
B-12418	Switch assembly, 2B, 30 point step switch	39	1.88
A-12431	Flat rail56
B-12435	Bayonet sockets & strip (6)		1.88
C-12437	Bayonet sockets & strip (7)		2.76
A-12460	Switch blade .020 thk., 5th cut, large hole14
A-12461	Switch blade .020 thk., 6th cut, large hole14
B-12462	Switch assembly, 1A, flipper	13	1.54
C-12463	Coin entrance housing	69	3.64
A-12464	Tie bar — 3-9/16"	67	.42
A-12465	Actuating rod — 4-1/16"	67	.30
A-12489	Coin entrance plate, 1 Bolivar — 3 plays	72	1.04
B-12490	Coin return housing	65	1.86
C-12493	Disc	47	5.00
A-12550	Armature switch bracket36
A-12555	Coin entrance plate, 20 cents — 3 plays	72	1.04
B-12566	Wiper		3.34
C-12567	Disc		18.00
B-12568	Wiper		3.50
B-12569	Disc		8.30
A-12570	Ball guide rail — wireform54
A-12584	Coin entrance plate, 2 nickels — 1 play		1.04
C-12587	Bayonet sockets & strip (6)		2.30
C-12619	Switch cam, 1 lobe — red	30	.26
A-12620	Formed switch blade20
B-12636	Flat rail84
B-12646	Switch assembly 1A, target bank	15	.82
B-12647	Switch assembly 1A, target bank	15	1.02
B-12648	Switch assembly 1A, 5B, motor	61	5.50
A-12653	Coin entrance plate, 50 P — 1 Peli	72	1.04
A-12654	Coin entrance plate, 1 MK — 3 Peli	72	1.04
A-12659	Target arm, daisy (specify color)	17	.46
B-12668	Switch assembly 2A, 1B, motor	61	2.34
A-12670	Disc		3.20
A-12671	Disc		3.20
A-12672	Pop bumper trim platter — cutoff14
B-12687	Bayonet sockets & strip (5)		2.00
B-12688	Bayonet sockets & strip (7)		2.86
B-12694	Switch assembly 5B, motor	61	4.70
C-12713	Bayonet sockets & strip (6)		2.36
B-12757	Wiper		8.80
A-12761	Bayonet sockets & strip (2)	51	.88
A-12764	Coin entrance plate, 10¢ — 1 play	72	1.04

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-12768	Top shelf (2 pos.)		2.32
B-12769	Bottom shelf (2 pos.)		2.22
A-12780	Coin entrance plate, 1/2 franc — 1 play		1.04
A-12781	Coin entrance plate, 1 Franc — 2 plays	72	1.04
A-12784	Coin entrance plate, 50 centimes — 1 play	72	1.04
B-12786	Frame		7.00
A-12790	Coin entrance plate, 30 yen — 1 play		1.04
A-12791	Coin entrance plate, 50 yen (new) — 2 plays	72	1.04
A-12796	Swinging target — checkered flag	20	3.24
B-12804	Switch assembly 2B, "AS" relay	59	1.48
B-12840	Bayonet sockets & strip (4)		1.68
A-12857	Coin entrance plate, 1 Franc — 4 plays	72	1.04
B-12881	Switch assembly 1A, rollover button	23	.92
B-12883	Switch assembly 3A, motor	61	2.58
A-12906	Dual Tee nut — 3/8 — 16 NC Thread44
B-13019	Wiper		5.00
B-13020	Disc		2.68
A-13101	Flat rail60
A-13136	Formed switch blade20
A-13149	Beaded flat rubber ring, 1" I.D. (red only)	13	.38
C-13150	Jumbo flipper (white only)	13, 14	.32
A-13151	Flat rubber ring 1-1/2" I.D. (red only)	13, 14	.22
A-13154	Jumbo flipper shaft	13, 14	1.20
C-13168	Plastic shield set		14.00
C-13172	Bayonet sockets & strip (8)		3.26
A-13176	Bumper cap — Diamond & 4 10s design	6	.36
A-13179	Target arm, star (specify color)	15	.46
A-13208	Coin entrance plate, 25 agorot — 1 play	72	1.04
A-13232	Coin entrance plate, 25 piastres — 1 play	72	1.04
A-13233	Coin entrance plate, 50 piastres — 2 plays	72	1.04
A-13278	Coin entrance plate, 5¢		1.04
A-13279	Coin entrance plate, 10¢		1.04
A-13280	Coin entrance plate, 25¢	72	1.04
A-13282	Coin entrance plate, 50 ore — 1 spel	72	1.04
B-13284	Switch assembly 2A, 1B, motor	61	2.54
A-13288	Gear & shaft		3.74
B-13294	Wiper		9.50
B-13295	Disc		5.50
B-13300	Target & switch assembly, 2A (specify color)		2.88
B-13301	Switch sub-assembly 2A, bank	56	1.46
B-13348	Bayonet sockets & strip (4)		1.60
A-13351	Coin entrance plate, 50 cents — 1 play	72	1.04
A-13353	Coin entrance plate, 1 shilling — 2 plays	72	1.04
A-13379	Coin entrance plate, 100 yen — 6 plays	72	1.04
A-13381	Coin entrance plate, 1 shilling	72	1.04
A-13383	Coin entrance plate, 2 x 1 franc	72	1.04
A-13385	Coin entrance plate, 1 franc	72	1.04
A-13387	Coin entrance plate, 50 pfennig	72	1.04
A-13389	Coin entrance plate, 100 lire	72	1.04
A-13391	Coin entrance plate, 100 yen	72	1.04
A-13393	Coin entrance plate, 5 pesetas	72	1.04

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-13395	Coin entrance plate, 1 krona	72	1.04
B-13396	Transformer		60.00
A-13397	Coin entrance plate, 20 centimes — 1 play		1.04
B-13400	Coin trough		1.52
B-13401	Coin trough cover		1.48
A-13402	Trigger shaft — 4 pos.	16	.74
A-13403	Trigger shaft — 5 pos.	16	1.10
B-13407	Reset arm assembly (4 pos.)	15	2.76
B-13408	Reset arm assembly (5 pos.)	15	2.78
C-13409	Pivot plate (4 pos.)	16	1.02
C-13410	Pivot plate (5 pos.)	16	1.22
C-13411	Switch plate (4 pos.)	16	1.08
C-13412	Switch plate (5 pos.)	16	1.32
C-13413	Guide plate (4 pos.)	16	.82
C-13414	Guide plate (5 pos.)	16	1.00
A-13437	Target arm — #2	15	.46
A-13438	Target arm — #3	15	.46
A-13439	Target arm — #4	15	.46
A-13440	Target arm — #5	15	.46
A-13441	Target arm — #6	15	.46
A-13442	Target arm — #7	15	.46
A-13443	Target arm — #8	15	.46
A-13444	Target arm — #9	15	.46
A-13445	Target arm — #10	15	.46
A-13446	Target arm — "J"	15	.46
A-13447	Target arm — "Q"	15	.46
A-13448	Target arm — "K"	15	.46
A-13449	Target arm — "A"	15	.46
B-13454	Switch assembly 4A, motor	61	3.92
A-13455	Reset arm return spring	15, 16	.10
A-13469	"Bat" label, small flipper, blue (left)22
A-13470	"Bat" label, small flipper blue (right)22
A-13471	"Bat" label, jumbo flipper, (specify red or blue)22
A-13472	"Bat" label, jumbo flipper, (specify red or blue)22
A-13474	Coin entrance plate, 2 x 5 francs	72	1.04
B-13540	Assembly of sockets & strip (5)		2.10
A-13542	Coin entrance plate, 100 lire — 1 play	72	1.04
A-13544	Coin entrance plate, 2 x 100 lire — 3 plays	72	1.04
A-13558	Coin entrance plate, 2 x 10 pfennig — 1 spiel		1.04
A-13560	Coin entrance plate, 50 pfennig — 3 spiele	72	1.04
A-13562	Coin entrance plate, 1 mark — 6 spiele	72	1.04
A-13584	Ball guide rail — wireform54
B-13602	Flat rail		1.12
D-13603	Top shield channel		1.70
D-13604	Top shield retainer88
A-13606	Gear & shaft		3.34
B-13613	Switch assembly 4A, motor	61	3.68
A-13615	Hole kicker		1.18
A-13616	Hole kicker		1.18
A-13618	Hole kicker		1.18
D-13635	Cabinet (without ball shooter cutout)		170.00

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
D-13647	Card holder	28	10.00
A-13652	Gate — wireform	19	.30
A-13653	Armature wireform	19	.28
A-13654	Gate shaft		1.04
A-13656	Shaft & collar assembly	19	1.08
A-13658	Frame & bushing		1.48
A-13660	Armature	19	.58
A-13663	Coin entrance plate, 50 pfennig — 2 spiele	72	1.04
A-13665	Coin entrance plate, 1 mark — 4 spiele	72	1.04
A-13667	Coin entrance plate, 2 marks — 10 spiele	72	1.04
B-13672	Switch assembly 1A, 2B, motor	61	2.32
B-13694	Switch assembly 2A, 2B, motor	61	2.96
A-13696	Ball guide rail — wireform30
E-13755	Score drum	46, 47, 49	1.62
B-13757	Switch assembly 1A, 6B, motor	61	5.10
D-13761	Card holder	28	9.50
B-13776	Switch assembly 1A, 1B, motor	61	1.96
A-13781	Target arm "horseshoe" design	15	.46
A-13782	Ball guide rail — wireform24
B-13794	Drum segment	46	.58
B-13795	Bayonet sockets & strip (5)		2.10
A-13798	Ball snubber — wireform08
C-13817	Drive finger "AS" relay	58	.26
A-13818	"AS" relay armature	58	1.40
A-13819	Armature finger spring	58	.22
A-13820	Coin entrance plate, 1 shilling — 2 plays	72	1.04
A-13824	Coin entrance plate, 2 francs — 10 plays	72	1.04
A-13833	Ball guide rail — wireform42
A-13853	Coin entrance plate, 50 centimos	72	1.04
A-13859	Bumper cap, diamond & 4 100's design	6	.36
B-13874	Flat rail58
B-13891	Flat rail62
A-13894	Vari-target disc		1.96
A-13895	Plastic target — wheel design36
C-13896	Coin entrance housing	69	3.46
A-13898	Flipper button strap	13, 79	.14
B-13899	Flipper button — replaced by B-16680		
C-13900	Flipper button bushing	13, 79	.26
B-13901	Shelf mounting bracket	51	.60
B-13902	Bottom shelf and slides (4 pos.)	51	2.64
B-13903	Top shelf and slides (4 pos.)	51	2.46
A-13904	Pop bumper body — 8 point star design (specify color)	6	.82
A-13905	Pop bumper body — 3 ring design (specify color).	6	.82
B-13910	Switch assembly 1A, 6B, motor	61	5.30
B-13911	Switch assembly 1A, 2B, motor	61	2.32
B-13913	Switch assembly 3A, 3B, motor	61	4.50
B-13915	Switch assembly 2A, 5B, motor	61	5.80
B-13930	Bayonet sockets & strip (9)		2.86
B-13940	Switch assembly 3A, 1B, motor	61	2.96
B-13941	Target & switch assembly, 1A (specify color)		2.88

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-13942	Switch assembly 2B, motor	61	1.72
B-13945	Switch sub-assembly, 1A, 1C, bank	54	1.72
B-13969	Switch assembly 1A, 2B, motor	61	2.56
A-13970	Post fastening screw cap		3.30 per 100
D-13976	Cabinet		170.00
D-13978	Stainless moulding (right side)		15.00
A-14002	Coil & stop mounting bracket10
A-14003	Assembly of coil stop mounting bracket	12, 44	1.04
C-14004	Bayonet sockets & strip (4)		1.64
D-14008	Front moulding	27	21.00
C-14010	Lock cam guide with screws	68	.68
B-14023	Sub-assembly frame, top mounting	32	7.90
A-14043	Swinging target shield	20, 21	.52
A-14044	"AS" relay armature	58	2.10
A-14045	"AS" relay ratchet and cams	58	1.58
A-14054	Coin entrance plate, 5 cents — 1 play	72	1.04
A-14056	Coin entrance plate, 10 cents — 2 plays	72	1.04
A-14058	Coin entrance plate, 25 cents — 4 plays	72	1.04
A-14060	Coin entrance plate, 25 cents — 5 plays	72	1.04
A-14062	Coin entrance plate, 50 lire — 1 play	72	1.04
A-14064	Coin entrance plate, 100 lire — 2 plays	72	1.04
A-14065	Stainless steel rivet		1.20 per 100
C-14078	Glass channel		2.00 set
B-14079	Glass seal replaced by A-15811		
A-14081	Coin entrance plate, 20 kopeks — 1 play	72	1.04
A-14083	Coin entrance plate, 20 francs — 1 play	72	1.04
A-14085	Coin entrance plate, 50 francs — 3 plays	72	1.04
B-14088	Switch assembly 2A, 2B, motor	61	3.88
A-14091	Bayonet sockets & strip (3 sockets)		1.22
A-14098	Metal flat rail60
A-14099	Gate, wireform	19	.30
B-14101	Disc		9.60
A-14104	Point burnishing tool	85	3.46
B-14105	Switch assembly 1A, 1B, motor	61	1.72
B-14106	Switch assembly 3A, 1B, motor	61	3.12
B-14107	Switch assembly 1B, score	45	.88
A-14110	Coin entrance plate, 2 plays — 5 P	72	1.04
A-14112	Coin entrance plate, 4 plays — 10 P	72	1.04
A-14113	Bottom shelf and slides — 2 pos.		1.54
B-14114	Top shelf and slides — 2 pos.		1.44
B-14158	Switch assembly 1C, motor	61	1.48
B-14163	Switch assembly 4A, motor	61	4.40
B-14165	Disc		1.10
B-14166	Wiper		1.40
B-14167	Disc		4.40
A-14170	Frame and bushing	19	1.22
A-14172	Coin entrance plate, 1 play — 1 P	72	1.04
A-14174	Coin entrance plate, 25¢ — 1 play	72	1.04
A-14176	Coin entrance plate, 1 Guilder — 5 plays	72	1.04
A-14179	Coin entrance plate, 1 Krona — 2 Spel.	72	1.04
A-14180	Line cord hole cover plate34

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
D-14183	Cabinet, triple chute, less trim — Germany		170.00
B-14235	Switch assembly 1A, motor	61	.90
A-14236	Rollunder gate spring	20	.22
A-14247	Coil housing — score unit	47	.42
A-14248	.010 thick switch blade14
B-14249	Switch assembly 1B, score	45, 47	.78
A-14251	Coin entrance plate, 20 cents — 2 plays	72	1.04
B-14253	Switch assembly 3A, 4B, motor	61	5.70
B-14254	Disc		3.30
C-14266	Plastic shield set (specify game)		17.00
A-14267	Metal flat rail62
A-14269	Coin entrance plate, 1 Sucre — 1 play	72	1.04
A-14271	Swinging target — 10	20	3.24
A-14273	Plastic target — football	22	.36
B-14279	Switch assembly 2A, 2B, motor	61	2.90
B-14281	Switch assembly 1A, 1C, motor	61	2.18
B-14283	Switch assembly 1A, 2C, motor	61	3.34
A-14286	Swinging target — football	20	3.24
D-14288	Cabinet — triple chute — less trim — Germany . .		170.00
A-14299	Metal flat rail66
A-14329	Metal card target	41	.08
B-14337	Switch assembly 2B, score	45	1.52
A-14375	Armature wireform	19	.26
A-14376	Shaft collar	19	1.08
A-14377	Metal flat rail52
C-14385	Plastic shield set (specify game)		16.00
D-14386	Card holder		10.00
A-14389	Metal flat rail78
A-14396	Plastic target — 4 star flash	22	.36
A-14401	Bumper cap — baseball	6	.36
A-14404	Plastic target — clown	22	.36
B-14406	Frame — roto		4.70
B-14412	Bank reset arm 9 pos. 2 coils		8.40
B-14413	Bank reset arm 10 pos. 2 coils		8.80
B-14414	Bank reset arm 11 pos. 2 coils		9.20
B-14415	Bank reset arm 12 pos. 2 coils		9.60
B-14418	Disc		2.26
B-14467	Switch assembly 1A, motor	61	1.20
B-14471	Knocker assembly		7.10
A-14473	Rollover wire and bracket30
C-14483	Plastic shield set (specify game)		17.00
A-14485	Target arm — clown	15	.46
A-14486	1-1/2" shield cover42
A-14487	Split post base	24	.08
A-14488	Split post cap	24	.06
A-14505	Ball guide rail — wireform30
A-14513	Contact kicker		1.46
A-14514	Swinging target — lion	20	3.24
B-14519	Disc		3.40
B-14521	Wiper		4.80
A-14527	Trigger shaft — 7 pos.	16	1.10

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-14529	Reset arm — 7 pos.	15	4.30
D-14530	Pivot plate — 7 pos.	16, 17	1.22
C-14531	Switch plate — 7 pos.	16, 17	1.32
C-14532	Guide plate — 7 pos.	16, 17	1.92
A-14533	Series bar — 4 pos.	16, 17	.62
A-14534	Series bar — 5 pos.	16, 17	.64
B-14535	Series bar — 7 pos.	16, 17	.66
B-14536	Series bar — 10 pos.	16, 17	.70
B-14540	Switch assembly 1C, motor	61	2.38
A-14545	Blank trim plate		1.12
B-14546	Switch assembly 2A, 2B, motor	61	2.88
B-14548	Switch assembly 1A, 3B, motor	61	2.94
A-14550	Coin entrance plate, 1 Guilder — 4 plays	72	1.04
B-14564	Switch assembly 2B, 1C, motor	61	2.44
B-14566	Disc		3.18
A-14571	Ball guide rail30
A-14572	Ball guide rail30
C-14574	Bayonet sockets and strip (15 sockets)		5.50
B-14575	Disc		5.10
B-14577	Wiper		3.20
C-14578	Disc		18.50
A-14594	Series bar switch plate	16	.14
A-14596	Tension blade and lifter	16	.62
B-14602	Transformer		46.00
C-14607	Plastic shield set (specify game)		14.50
B-14644	Switch assembly 2A, motor	61	1.96
B-14646	Switch assembly 4B, motor	61	2.96
B-14648	Switch assembly 1B, motor	61	1.44
B-14649	Switch assembly 2A, motor	61	1.86
B-14650	Switch assembly 1A, rollover	23	1.06
A-14653	Tilt bob adjust clip (use only with A-15164)	84	.08
B-14654	Disc		5.00
C-14665	Plastic shield set (specify game)		14.50
A-14671	Bumper cap — pennant	6	.36
B-14683	Bayonet sockets and strip (7 sockets)		2.54
A-14685	Contact kicker		1.46
B-14689	Metal flat rail52
A-14694	Coin entrance plate, 1 Franc — 3 plays	72	1.04
C-14695	Transformer cage		7.60
B-14696	Switch assembly 1A, 5B, motor	61	5.40
A-14698	Bumper cap — racked balls	6	.36
A-14700	Target arm — rack and balls	15	.46
C-14703	Disc		12.50
B-14704	Wiper		5.00
A-14705	Inter-lock switch mounting bracket52
B-14707	Frame		4.10
B-14723	Line cord — 3 wire 15 ft.		7.00
B-14724	Metal kick plate		1.20
B-14742	Metal flat rail46
C-14751	Plastic shield set (specify game)		14.50
A-14753	Gear & shaft		3.74

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-14754	Unit mounting bracket	37	.48
A-14755	Unit mounting bracket	37	.54
A-14773	Coin entrance plate, 2 Francs — 6 plays	72	1.04
B-14774	Switch assembly 2A, motor	61	2.18
B-14779	Disc		6.50
A-14784	Coin entrance plate, 100 Yen — 4 plays	72	1.04
A-14787	Plastic target — Star	22	.36
A-14788	Plastic target — Aztec	22	.36
B-14789	Switch assembly 3A, 1B, motor	61	2.96
A-14792	Mini post screw	24	.26
A-14793	Rubber ring — mini post screw 23/64" dia.	24	.06
A-14797	Drive ratchet bearing	42, 43	.08
A-14798	Add dial	43	.20
A-14801	0-9 subtract dial	43	.60
A-14802	Drive pawl spring	42, 43	.06
A-14803	Ratchet pawl wireform	42, 43	.04
A-14804	Formed switch blade		.14
A-14805	Ratchet pawl clip	17, 42, 43	.12
A-14806	Unit mounting leg	42	.30
A-14807	Unit mounting plate		.30
B-14808	Bearing plate	42, 43	1.62
B-14809	Dial mask	43	.36
B-14810	Drive pawl	42, 43	.12
C-14811	Drive ratchet	43	.46
C-14812	Short drive ratchet	42	.26
C-14813	Subtract ratchet	43	.42
C-14814	Short subtract ratchet	42	.28
C-14815	Frame	33	3.00
A-14833	Contact kicker	10	1.46
A-14834	Contact kicker	10	1.46
A-14835	Contact kicker		1.46
A-14836	Contact kicker	44	1.46
C-14844	Plastic shield set (specify game)		14.50
A-14857	Target arm — bowling pin	15	.46
B-14858	Disc		6.20
A-14859	Pop bumper trim platter		.22
A-14860	Metal flat rail		.42
A-14861	Metal flat rail		.54
A-14867	Coin entrance plate, 50 Yen — 1 play	72	1.04
A-14869	Coin entrance plate, 100 Yen — 3 plays	72	1.04
B-14904	Disc		1.42
B-14905	Wiper		1.52
D-14906	Card holder		10.00
E-14910	Card holder	28	10.00
D-14911	Card holder		10.00
B-14921	Wiper		10.50
A-14927	Vari-target disc		1.34
A-14932	Coin entrance plate, 1 Dinar — 1 play	72	1.04
A-14934	Coin entrance plate, 2 x 1 Dinar — 3 plays	72	1.04
A-14936	Target arm — Indian	15	.46
A-14938	Bumper cap — 1000 points	6	.36

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
C-14961	Plastic shield set (specify game)		14.50
B-14972	Coin trough — 1 Peso	69	1.54
A-14999	Subtract pawl compression ring	43	.44
A-15000	Sub-assembly drive pawl	43	1.28
B-15001	Switch assembly — pawl	42, 43	.50
B-15003	Switch assembly 2A, credit unit	42, 43	1.64
B-15004	Disc		3.00
A-15035	Coin entrance plate, 2 x 10 Peso — 1 play	72	1.04
A-15036	Bat label — Fullback22
A-15037	Bat label — Halfback22
A-15038	Bat label — Quarterback22
A-15039	Bat label — Flankerback22
C-15047	Plastic shield set (specify game)		14.50
B-15050	Disc		19.50
B-15051	Wiper		8.90
B-15052	Metal flat rail70
B-15054	Bayonet sockets and strip (7)		2.70
D-15062	Plastic shield set (specify game)		15.50
B-15068	Front door hinge82
D-15073	Assembly of door frame and hinge	74, 75	11.00
E-15074	Front panel — door	74	13.00
C-15077	Back panel — door	75	11.50
B-15078	Coin entrance plate retainer66
C-15079	Coin entrance housing — 1 chute	74	5.20
C-15080	Coin entrance housing — 2 chute	74	5.20
C-15081	Coin entrance housing — 3 chute	74	5.20
A-15082	Coin feed trough	78	1.36
A-15083	Coin feed trough cover	78	1.36
A-15084	Coin feed trough cover	78	1.46
A-15085	Trough guide bracket26
B-15088	Coin guide trough	75, 76	2.50
A-15090	Reject rod	77	1.60
A-15091	Reject shaft	76	1.50
A-15092	Reject lever	76	.26
A-15093	Reject arm	76	.16
B-15094	Reject bracket	76	.44
B-15095	Assembly reject mechanism — 1 chute	76	4.70
A-15098	Coin return door	76	.50
B-15101	Coin return cover	78	2.92
C-15102	Coin return housing	78	1.30
B-15103	Coin lockout actuating rod	79	.60
C-15104	Cashbox cover		2.30
D-15106	Lockdown moulding slide	27	7.30
B-15114	Metal kick plate		1.20
D-15117	Cabinet — less trim		170.00
B-15155	Fence58
A-15157	Coin entrance plate, 20 cents — 1 play		1.04
A-15159	Coin entrance plate, 2 x 20 cents — 1 play	72	1.04
A-15160	Coin entrance plate, 20 Francs — 1 play	72	1.04
B-15163	Switch housing	64	.24
A-15164	Tilt bob wire	84	.14

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-15166	Bumper cap — moves 10 X target light	6	.36
B-15168	Bayonet sockets and strip (14 sockets)		5.00
A-15177	Target arm — bullseye	15	.46
B-15179	Bayonet sockets and strip (10 sockets)		2.94
B-15180	Disc		5.30
B-15195	Frame		5.80
A-15200	Bumper cap — Quad Star	6	.48
A-15202	Target arm — #1	15	.46
C-15206	Plastic shield set (specify game)		14.50
A-15208	Bayonet sockets and strip (5 sockets)		1.62
B-15209	Disc		5.00
B-15210	Wiper		7.00
B-15211	Switch assembly 1A, 1B, "AG" relay	56	1.62
C-15221	Nylon cam 4 point A, "AS" relay	58	.44
A-15222	"AS" relay ratchet and 4 point cam	58	1.42
A-15224	Contact kicker		1.46
A-15245	Coin entrance plate, 5 Peseta — 1 play	72	1.04
A-15247	Coin entrance plate, 25 Peseta — 6 plays	72	1.04
A-15258	Drive coil plunger	49	.24
A-15259	Drive coil	49, 81	1.76
B-15260	Coil case28
A-15261	Drive spool bearing	49	.08
A-15262	Lockin switch override stop08
C-15263	Switch actuator	49	.16
D-15264	Drive rack slide	49	.28
B-15267	Disc (use A-15909)		
A-15271	Coin entrance plate, 1 Peso — 1 play	72	1.04
B-15273	Disc		8.40
B-15274	Wiper		4.44
C-15275	Disc		13.00
A-15288	Plastic target — Diamond	22	.36
A-15290	Plastic target — Heart	22	.36
C-15297	Plastic shield set (specify game)		14.50
A-15300	Snap spring lock	50	.30
D-15307	4 position top shelf	50	5.40
D-15308	4 position center shelf	50	8.20
D-15309	4 position bottom shelf	50	5.80
D-15310	Assembly 4 position frame (16 units)	50	28.00
B-15312	4 position top shelf	51	2.50
B-15313	4 position center shelf	51	3.96
B-15314	4 position bottom shelf	51	2.68
D-15315	Assembly 2 position frame (8 units) vert.	51	15.00
D-15316	8 position top shelf		6.80
D-15317	8 position bottom shelf		7.10
D-15318	Assembly 2 position frame (8 units) horiz.		18.50
A-15338	Interlock switch and bracket		3.30
A-15352	Front door interlock parts kit	86	20.00
A-15354	Coin entrance plate, 2 x 25¢ — 3 plays	72	1.04
A-15355	Coin entrance plate, 25¢ — 1 play	72	1.04
B-15357	Line cord 3 wire — 15 ft.		3.86
A-15359	Coil		1.76

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-15365	Coin entrance plate, 1 Mark — 2 Spiele	72	1.04
A-15367	Coin entrance plate, 2 Marks — 5 Spiele	72	1.04
A-15369	Coin entrance plate, 50 Pfennig — 1 Spiel	72	1.04
B-15370	Switch assembly 3A, motor	61	2.30
A-15387	Switch lever	44	.24
A-15388	Ball snubber18
A-15389	Switch guard20
A-15390	Ball guide	44	.44
B-15391	Ball guide	44	.68
B-15392	Top track	44	1.00
B-15393	Bottom track	44	.76
B-15395	Sweep arm guard	44	.38
B-15396	Assembly sweep arm	44	3.00
D-15397	Frame (display unit)	44	6.30
A-15401	On-off switch	64	1.04
A-15409	Coil mounting bracket	42, 43, 80	.22
A-15410	Coil and stop mounting bracket22
A-15412	Coin entrance plate, 50 Yen — 1 play	72	1.04
A-15414	Coin entrance plate, 100 Yen — 3 plays	72	1.04
A-15416	Target arm — Checkered	15	.46
A-15437	Front plate	62	2.34
A-15438	Back plate	62	2.46
A-15439	Coil and stator core	62	6.60
A-15440	Mounting stud	62	.24
A-15441	1/4" spacer	62	.20
A-15442	Rotor assembly	62	3.30
A-15443	Steel rotor washer	62	.10
A-15444	Fibre rotor washer	62	.10
A-15445	Bearing — 5/32"	62	.10
A-15446	Bearing — 1/8"	62	.10
A-15447	Bearing — 1/4"	62	.14
A-15448	Rotor shaft assembly	62	1.44
A-15449	1st reduction assembly	62	1.88
A-15450	2nd reduction assembly	62	3.08
A-15451	Output shaft assembly	62	3.00
A-15452	Front plate	62	2.34
A-15453	Back plate	62	2.46
A-15454	2nd reduction assembly	62	3.08
A-15455	Output shaft assembly	62	3.00
B-15462	Knocker mounting strip	80	.68
B-15463	Knocker assembly	80	4.90
A-15467	Coin entrance plate, 10 Kronur — 1 play	72	1.04
A-15469	Coin entrance plate, 50 Kronur — 6 plays	72	1.04
B-15470	Disc		7.20
B-15471	Wiper		7.90
A-15476	Coin entrance plate, 50 Rupiah — 1 play	72	1.04
A-15480	Lightbox glass wedge	29	.16
A-15481	Lightbox glass wedge	29	.14
A-15483	Assembly jumbo flipper & shaft	13	2.00
A-15487	Coin entrance plate, 50 AG — 1 play	72	1.04
A-15491	Coin entrance plate, 1 Mark — 3 Spiele	72	1.04

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-15493	Coin entrance plate, 2 Mark — 6 Spiele	72	1.04
A-15495	Coin entrance plate, 2 Mark — 7 Spiele	72	1.04
B-15497	Switch assembly 2A, 5B, motor	61	5.20
B-15503	Reset arm — 10 position	16	4.40
C-15504	Coil setup bracket	16	.54
C-15505	Coil setup bracket	16	.54
A-15507	Target arm — Fish46
C-15524	Disc		15.00
C-15528	Bearing bracket	14	.38
A-15529	Flipper shaft bearing, top	14	.18
A-15531	Sub-assembly, flipper shaft	14	1.20
A-15540	Barrel spring (shock mount)04
A-15549	Arch gate — cutoff50
A-15550	Assembly arch gate		1.12
B-15551	Metal flat rail60
A-15555	Coil	81	2.76
C-15565	Plastic shield set (specify game)		15.50
A-15566	Tilt delay kit — multiple player	86	7.60
A-15567	Tilt delay kit — single player	86	10.50
A-15575	Coin entrance plate, 2 Francs — 5 plays	72	1.04
A-15576	Pop bumper trim platter — cutoff16
B-15595	Switch assembly 1C, display unit	44	1.14
A-15596	"AS" relay disc		4.30
A-15597	Circuit delay module	64	5.40
A-15598	Hole kicker spring	9	.14
B-15601	Disc		2.52
B-15602	Wiper		4.30
A-15606	Motor cam assembly		4.80
A-15607	Motor cam assembly		5.00
B-15609	Metal flat rail48
A-15611	Gear and shaft		3.74
A-15617	Trigger shaft — 9 position	16	1.08
B-15618	Series bar — 9 position	16	.68
B-15619	Reset arm — 9 position	16	3.70
D-15620	Pivot plate — 9 position	16	2.52
D-15621	Switch plate — 9 position	16	2.40
D-15622	Guide plate — 9 position	16	2.66
B-15623	Counter mounting bracket28
B-15629	Metal flat rail66
C-15645	Plastic shield set (specify game)		14.50
C-15646	Mini post rollover guide — 1-1/2" (specify color)	24	.44
C-15647	Mini post rollover guide — 2" (specify color)	24	.48
C-15648	Mini post rollover guide — 2-1/2" (specify color)	24	.54
C-15658	"AS" relay cam	58	.30
A-15659	"AS" relay ratchet and cams	58	1.60
A-15661	Target arm — "Cowboy"	15	.46
A-15663	Target arm — "Catcus"	15	.46
A-15665	Target arm — "Horse"	15	.46
A-15667	Coin entrance plate, 1 Partida — 1 Ficha	72	1.04
B-15684	Interlock relay housing	60	1.00
C-15685	Interlock relay mounting frame	60	.90

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-15687	Reset arm bearing	16	.06
B-15689	Reset arm — 4 position	16	3.00
B-15691	Reset arm — 5 position	16	3.02
B-15693	Reset arm — 7 position	16	4.20
A-15696	Outboard bearing bracket	16	.04
B-15704	Dip target switch assembly, 1A	22	1.48
A-15705	Rubber ring — mini post screw 27/64 dia.	24	.06
A-15706	"AS" relay disc		3.20
C-15707	Hole base plate (specify color)	9	.28
C-15708	Hole switch arm (specify color)	9	.28
C-15724	Plastic shield set (specify game)		14.50
C-15725	Roto unit shield support bracket66
A-15734	Card target plastic set (sold in sets only)	41	5.00
	Card target plastic set riveted to A-4345 blade (sold in sets only)	41	10.00
C-15735	Disc		16.00
C-15737	Roto wiper and targets		20.00
A-15745	Bumper cap — Jester	6	.36
A-15747	Dip target — 500 when lit	22	.70
A-15749	Dip target — 3000 when lit	22	.70
B-15767	Frame — roto unit		4.80
B-15768	Switch assembly 1B, motor	61	1.04
B-15771	Target and switch assembly (specify color)		2.20
A-15775	Coin entrance plate, 1 Krona — 1 Spel	72	1.04
B-15778	Switch assembly 5B, motor	61	4.70
C-15781	Plastic shield set (specify game)		14.50
A-15806	Vari-target disc		1.72
B-15807	Metal flat rail52
A-15811	Glass seal	26	.34
A-15816	Coin entrance plate, 2 x 2 Zlote — 1 play	72	1.04
A-15818	Coin entrance plate, 1 Krone — 1 play	72	1.04
A-15819	Fulcrum	9, 11	.12
A-15822	Sub-assembly ball cam	9	.70
A-15824	Sub-assembly twin tip ball cam		1.36
A-15826	Sub-assembly spring cam	9	.58
A-15827	Assembly hole kicker	9	1.80
A-15828	Assembly hole kicker	9	1.80
A-15829	Assembly hole kicker		1.80
A-15832	Sub-assembly kicker arm	11	.74
A-15833	Sub-assembly kicker arm	11	.74
A-15834	Sub-assembly kicker arm	11	.74
A-15835	Sub-assembly kicker arm	11	.74
A-15836	Assembly contact kicker		1.46
A-15837	Assembly contact kicker		1.46
A-15838	Assembly contact kicker	11	1.46
A-15839	Assembly contact kicker	11	1.46
A-15845	Pop bumper trim platter — cutoff16
B-15856	Switch assembly 1A, door	75, 79	1.64
A-15858	Bayonet socket	75	.40
C-15864	Plastic shield set (specify game)		15.50
B-15866	Disc		7.60

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-15867	Frame		4.60
C-15873	Plastic shield set (specify game)		14.00
A-15877	Trip arm wireform	17	.06
A-15878	Trip arm trigger shaft	17	.74
B-15880	Trip coil bracket — left	17	.70
B-15881	Trip coil bracket — right	17	.70
B-15883	Assembly trip arm — 5 position	17	2.70
B-15884	Assembly trip arm — 5 position	17	2.70
B-15888	Switch assembly 2A, 2B, motor	61	2.94
B-15903	Switch assembly 2A, 1B, score unit	45	2.34
B-15904	Switch assembly 1A, 1B, score unit	45	1.46
B-15905	Switch assembly 1B, score unit	45	.86
B-15906	Switch assembly 2B, score unit	45	1.60
B-15908	Frame — score unit	49	1.62
A-15909	Score unit disc	49	2.12
A-15910	Spring washer	49	.02
A-15911	Coil mounting bracket and stop	49	.74
A-15915	Bumper cap — Tiger	6	.36
B-15919	Switch assembly 2A, motor	61	1.68
A-15920	Dip target mounting bracket — 1-3/16	22	.26
A-15921	Dip target mounting bracket — 1-5/8	22	.26
B-15924	Switch assembly 6B, motor	61	5.00
A-15938	Interlock switch mounting bracket		.30
A-15939	Gear and shaft		3.74
B-15943	Disc		3.92
C-15963	Plastic shield set (specify game)		15.50
B-15983	Switch assembly 1B, kicking rubber	11	1.04
A-15985	Coin entrance plate, 1 play — 5 P	72	1.04
A-15987	Coin entrance plate, 2 plays — 10 P	72	1.04
B-15991	Target and switch assembly (specify color)		2.20
A-15993	Interlock relay armature and tip	60	.50
B-15997	Switch assembly 1A, hole kicker	9	.92
B-15998	Switch assembly 2A, hole kicker	9	1.68
B-15999	Switch assembly 2A, hole kicker	9	1.68
A-16000	Frame and plate — replay unit	43	2.40
A-16002	Bayonet socket		.22
A-16026	Gear and shaft		3.74
C-16030	Coin entrance housing — Mondial — 1 chute		3.80
C-16034	Coin entrance mounting plate		2.88
A-16036	Ball guide rail — wireform		.28
A-16037	Ball guide rail — wireform		.28
A-16038	Ball snubber		.28
A-16043	Sub-assembly spring cam	9	.58
A-16044	Sub-assembly ball cam	9	.70
A-16045	Assembly — hole kicker	9	1.80
B-16049	Plastic shield set (specify game)		14.00
B-16050	Disc		2.20
A-16061	Lockin switch override stop		.18
B-16062	Switch assembly 1A, 1B, score unit	45	1.72
A-16079	25¢ — 1 play, 2 x 25¢ — 3 plays label		.50
A-16083	Assembly — hole kicker	9	1.80
A-16084	Lifter Blade		.10

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-16085	Assembly — hole kicker	9	1.80
A-16086	Assembly — hole kicker	9	1.80
A-16087	Gate — wireform16
A-16088	Assembly ball snubber gate	44	.42
C-16091	Plastic shield set (specify game)		14.50
B-16095	Coin return housing		1.96
C-16111	Plastic shield set (specify game)		14.00
A-16115	Target arm — Surfer	15	.46
A-16116	Spinning target — Surfer	20	3.16
B-16117	Frame		3.78
A-16118	Metal flat rail60
A-16142	Score card cover08
A-16143	Instruction card cover14
A-16146	Bottom track deflector	44	.32
A-16150	Coin entrance plate, 2 x 5 Pesetas — 1 play	72	1.04
A-16152	Coin entrance plate, 25 Pesetas — 3 plays	72	1.04
A-16154	Gear and shaft		3.74
C-16177	Plastic shield set (specify game)		15.00
B-16182	Switch assembly 1A, ball return	9	1.04
A-16183	Series bar — 2 position	15	2.00
A-16186	Top arch track		1.24
A-16188	Dip target — 5	22	.70
A-16190	Dip target — 6	22	.70
B-16192	Drive coil housing, 30 point step switch	17, 32, 33, 34	.80
B-16194	Drive coil housing, bank reset	16, 52	1.10
A-16196	25¢ — 1 play, illuminated label	71	.36
C-16221	Bayonet sockets and strip (21)		6.50
A-16227	Coin entrance plate, 50 Piastres — 1 play	72	1.04
A-16229	Coin entrance plate, 2 x 50 Piastres — 3 plays	72	1.04
C-16236	Plastic shield set (specify game)		14.50
A-16240	Coin entrance plate, 2 x 20 cents — 4 plays	72	1.04
C-16246	25¢ — 1 play, 2 x 25¢ — 3 plays conversion kit	86	30.00
B-16248	Metal flat rail60
A-16251	Coil		2.10
A-16273	"AS" relay disc		4.30
D-16274	Nylon shaft bearing	37	.20
B-16280	Switch assembly 1A, display unit	44	1.04
A-16293	"AS" relay ratchet and cams	58	1.70
B-16297	Switch assembly 2A, 1B, motor	61	2.16
A-16299	Coin entrance plate, 2 Mark — 9 Spiele	72	1.04
B-16300	Switch assembly 3A, credit unit	43	2.20
A-16305	Swinging target — bowling ball and pins	20	3.24
B-16310	Disc		3.92
B-16311	Wiper		5.50
B-16312	Disc		2.96
A-16324	White lube, 1/2 oz. tube96
A-16325	Black lube, 1/2 oz. tube96
A-16335	Coin feed trough	78	1.52
A-16336	Coin feed trough cover	78	1.48
A-16337	Coin feed trough	78	1.52
B-16338	Coin chute saddle	75, 77	2.30

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-16339	Coin entrance housing — Mondial — 1 chute . . .		5.20
B-16340	Coin entrance housing — Mondial — 2 chute . . .		5.20
B-16342	Coin return cover — 1 chute	78	2.92
B-16344	Coin return cover — 2 chute	78	2.92
D-16345	Cashbox		6.00
B-16348	Switch assembly 1A, 3B, motor	61	2.94
B-16349	Switch assembly 1B, motor	61	1.44
B-16350	Switch assembly 2A, 2B, motor	61	2.94
A-16351	Mini pry bar	85	1.86
D-16352	Cabinet, less trim — Germany		170.00
C-16354	Frame, flipper unit — right	14	1.30
C-16355	Frame, flipper unit — left	14	1.30
A-16356	Coil mounting bracket	14	.10
A-16360	Assembly of plunger and tip	14	1.00
A-16361	Flipper lever and screws	14	1.90
A-16362	Assembly flipper lever, plunger and tip	14	3.30
A-16363	Switch assembly 1B, flipper unit	14	1.16
A-16364	Stop stem06
A-16365	Stop collar06
A-16366	Stop shading ring04
A-16367	Stop bushing	81	.02
C-16373	Plastic shield set (specify game)		14.50
A-16381	Swinging target switch rod	20	.22
A-16382	Swinging target switch weight	20, 21	.32
B-16384	Switch assembly 1B, swinging target	20	.86
B-16387	Disc		5.00
B-16388	Wiper		6.30
B-16402	Switch assembly 2A, motor	61	1.96
C-16404	Assembly trip arm (9 pos.)	17	2.84
C-16405	Assembly trip arm (9 pos.)	17	2.84
A-16406	Trip arm trigger shaft (9 pos.)	17	.78
C-16410	Plastic shield set (specify game)		14.00
A-16439	Swinging target — skull and crossbones	20	3.24
A-16451	Metal flat rail32
A-16452	Metal flat rail72
B-16464	Disc		8.50
B-16465	Wiper		2.76
C-16484	Dual light divider — 100,000 light	29	.36
A-16489	Switch actuator shaft — decagon unit	49	.12
A-16501	Coin entrance plate — 1 MK — 2 Pelia	72	1.04
B-16505	Switch assembly 1B, 3A, motor	61	3.22
A-16507	Printed insert, 10¢ — 1 play	73	.08
A-16509	Printed insert, 25¢ — 1 play	73	.08
A-16510	Printed insert, 25¢ — 2 plays	73	.08
A-16511	Printed insert, 25¢ — 3 plays	73	.08
A-16514	Printed insert, 20¢ — 1 play	73	.08
A-16515	Printed insert, 20¢ — 2 plays	73	.08
A-16516	Printed insert, 2 x 20¢ — 3 plays	73	.08
A-16517	Printed insert, 2 x 20¢ — 4 plays	73	.08
A-16519	Printed insert, 1 Franc — 2 plays	73	.08
A-16520	Printed insert, 2 Francs — 5 plays	73	.08

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-16521	Printed insert, 5 Francs — 1 play	73	.08
A-16522	Printed insert, 10 Francs — 2 plays	73	.08
A-16527	Printed insert, 2 x 1 Peseta — 1 play	73	.08
A-16528	Printed insert, 5 Peseta — 3 plays	73	.08
A-16529	Printed insert, 2 x 5 Pesetas — 1 play	73	.08
A-16530	Printed insert, 25 Pesetas — 3 plays	73	.08
A-16531	Printed insert, 1 Krone — 1 play	73	.08
A-16533	Printed insert, 5 P — 1 play	73	.08
A-16534	Printed insert, 10 P — 2 plays	73	.08
A-16535	Printed insert, 50 Pfennig — 1 Spiel	73	.08
A-16536	Printed insert, 50 Pfennig — 2 Spiele	73	.08
A-16537	Printed insert, 1 Mark — 2 Spiele	73	.08
A-16538	Printed insert, 1 Mark — 3 Spiele	73	.08
A-16539	Printed insert, 1 Mark — 4 Spiele	73	.08
A-16540	Printed insert, 2 Mark — 5 Spiele	73	.08
A-16541	Printed insert, 2 Mark — 6 Spiele	73	.08
A-16542	Printed insert, 2 Mark — 7 Spiele	73	.08
A-16543	Printed insert, 2 Mark — 8 Spiele	73	.08
A-16544	Printed insert, 2 Mark — 9 Spiele	73	.08
A-16546	Printed insert, 50 Lire — 1 play	73	.08
A-16547	Printed insert, 100 Lire — 1 play	73	.08
A-16548	Printed insert, 100 Lire — 2 plays	73	.08
A-16549	Printed insert, 50 Piastres — 1 play	73	.08
A-16550	Printed insert, 2 x 50 Piastres — 3 plays	73	.08
A-16551	Printed insert, 1 Guilder — 4 plays	73	.08
A-16553	Printed insert, 1 Krona — 1 Spel	73	.08
A-16559	Printed insert, 50 Yen — 1 play	73	.08
A-16560	Printed insert, 100 Yen — 3 plays	73	.08
C-16561	Coin entrance plate — no opening	71	.68
C-16562	Coin entrance plate	71	.68
C-16563	Coin entrance plate	71	.68
C-16564	Coin entrance plate	71	.68
C-16565	Coin entrance plate	71	.68
C-16566	Coin entrance plate	71	.68
C-16567	Coin entrance plate	71	.68
C-16568	Coin entrance plate	71	.68
C-16573	Switch cam — 5 lobes — green	31	.26
C-16574	Switch cam — 1 lobe — black26
A-16575	Cam retainer	31	.18
A-16576	Switch mounting strip (3 pos.)	31	.48
A-16577	Gear and shaft	31	3.24
A-16579	Coin entrance plate — 20¢	72	1.04
A-16580	Printed insert, 20¢	73	.08
B-16584	Disc		4.50
A-16585	Gear and shaft		3.24
A-16586	Gear and shaft		3.24
C-16594	Plastic shield set (specify game)		14.00
C-16597	Disc		14.00
B-16598	Wiper		7.20
A-16616	Printed insert, 100 Yen — 2 plays	73	.08
A-16618	Coin entrance plate, 100 Yen — 2 plays	72	1.04

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-16624	"AS" relay outboard bearing	59	.42
A-16625	"AS" relay outboard bearing	59	.42
B-16628	Cashbox locator assembly		1.38
B-16632	Pop bumper pad	3	.68
A-16634	Tie rods and ring	3	1.36
A-16636	Bumper contact blade		.26
A-16637	Bumper contact blade and point	2, 5	.36
A-16647	Bumper switch mounting bracket		.34
A-16675	Printed insert, 50 P — 1 play	73	.08
A-16676	Printed insert, 1 MK — 2 plays	73	.08
B-16680	Flipper button	13, 79	.36
A-16695	Switch guard		.06
A-16700	Sub-assembly contact kicker arm		.80
A-16701	Assembly contact kicker		1.50
A-16702	Printed insert, 2 x 5 Francs — 1 play	73	.08
A-16703	Printed insert, 10 Francs — 1 play	73	.08
B-16709	Metal flat rail		.66
B-16712	Metal flat rail		.66
C-16716	Plastic shield set (specify game)		14.00
B-16722	Transformer		66.00
B-16733	Wiper		3.60
A-16734	Printed insert, 25¢	73	.08
D-16745	Lightbox assembly — 4 player	29	85.00
A-16748	Bumper cap — "500 when lit"	6	.36
C-16755	Plastic shield set (specify game)		15.50
D-16758	Metal lightbox door	29	14.50
A-16836	Gear and shaft	58	3.24
A-16838	Bumper cap — Superposed Star	6	.36
A-16861	Motor cam		5.80
B-16879	Switch assembly 1A, 2B, credit replay unit		2.14
A-16880	Printed insert, 1 Markka — 1 Peli	73	.08
A-16883	Bumper cap — Starburst	6	.36
B-16884	Disc		5.20
A-16890	Coil		2.16
A-16892	"AG" relay armature and insulator arm	56	.72
A-16893	"AG" relay armature and insulator arm	56	.76
A-16894	Card target plastic set (sold in sets only)		5.00
	Card target plastic set riveted to A-4345 blade (sold in sets only)		10.00
A-16900	Disc — vari-target		1.72
B-16901	Disc		14.00
B-16902	Wiper		6.20
C-16903	Disc		16.00
A-16930	Anti-cheat delay kit	86	8.50
C-16931	Wiper and targets		20.00
D-16949	Lockdown moulding slide	27	7.60
D-16951	Lockdown moulding	27	14.00
A-16962	Metal shield — roto unit		.70
C-16967	Plastic shield set (specify game)		16.00
C-16969	Sub-assembly frame — right	14	2.80
C-16970	Sub-assembly frame — left	14	2.80

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-16971	Switch mounting bracket34
B-16972	Switch assembly, 2A, replay unit	38	1.70
B-16973	Switch assembly, 1A, replay unit	38	1.52
D-16975	4 position frame module	50	29.00
A-16976	Ball guide strip36
C-16990	Plastic shield set (specify game)		14.50
B-17029	Transformer		66.00
B-17033	Switch assembly, 1B, kicking rubber		1.04
A-17037	Backing blade	82	.14
B-17039	Switch assembly, 1B, anti-cheat	79	1.14
C-17042	Plastic shield set (specify game)		14.00
D-17045	Cabinet assembly (less trim)		170.00
C-17047	Disc		16.50
B-17048	Wiper		7.30
A-17050	Label — D. Gottlieb & Co.40
A-17086	Target arm — "single"	15	.46
A-17088	Target arm — "double"	15	.46
A-17090	Target arm — "triple"	15	.46
B-17091	Switch assembly 1B, replay unit	34	1.50
A-17106	Ball guide rail — wireform24
B-17107	Switch assembly — less bracket — pop bumper	2, 3	1.50
B-17108	Switch assembly — with bracket — pop bumper	5	2.34
B-17109	Switch assembly — with bracket — pop bumper	2, 3, 5	2.34
A-17118	Target arm — "C"	15	.46
A-17120	Target arm — "D"	15	.46
A-17122	Target arm — "N"	15	.46
A-17124	Target arm — "R"	15	.46
A-17126	Target arm — "Y"	15	.46
A-17128	Target arm — shield	15	.46
A-17129	Backing blade06
A-17130	Plastic target and blade (specify color)70
A-17133	Ribbon — red and white		1.20
A-17134	Ribbon clamp16
A-17135	Plastic spool10
A-17136	Spool shaft30
A-17137	Spring10
C-17138	Ribbon drum		1.00
C-17139	Ribbon column housing		2.20
C-17141	Frame — ribbon unit		4.50
B-17142	Indicator strip — paper10
A-17147	Target arm — 500	15	.46
A-17173	Swinging target switch rod	21	.12
B-17175	Plastic swinging target	21	1.00
A-17177	Printed insert, 2 Drachmai — 1 play	73	.08
A-17178	Printed insert, 5 Drachmai — 3 plays	73	.08
A-17179	Coil stop stem and collar — #10-32	81	.66
A-17181	Target arm — Monkey	15	.46
A-17183	Coil stop and #10-32 elastic stop nut	42, 43, 81	.76
A-17185	Coil mounting bracket and stop	14	1.04
A-17187	Coil mounting bracket and stop	2, 3	2.64
A-17191	Coil mounting bracket and stop	30, 31	1.72
A-17193	Coil mounting bracket and stop		1.72

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
A-17195	Coil mounting bracket and stop	34	1.04
A-17197	Coil mounting bracket and stop	17, 32, 33, 34	1.20
A-17198	Coil mounting bracket and stop	16, 52	1.20
A-17219	Coil mounting bracket and stop		1.04
C-17231	Plastic shield set (specify game)		14.50
A-17234	Replay window mask20
B-17276	Disc		5.60
B-17277	Wiper		5.70
B-17292	Disc		6.80
A-17294	Cashbox bumper strip10
A-17297	Light divider06
A-17299	Gate10
A-17300	Gate shield28
B-17301	Metal flat rail72
B-17302	Metal flat rail64
A-17305	Gear and shaft		3.24
A-17316	Switch backing bracket06
A-17343	Coil mounting bracket and stop	49	.92
B-17344	Switch assembly, 1A, score unit86
A-17350	Gear and shaft		3.24
A-17354	Printed insert, 3 x 1 Sucre - 1 play	73	.08
A-17355	Printed insert, 5 x 1 Sucre - 2 plays	73	.08
A-17356	Printed insert, 1 Franc	73	.08
A-17359	1 Franc - 1 play, 2 x 1 Franc - 3 plays label50
C-17367	Coin entrance housing - 1 chute	74	5.20
B-17368	Coin entrance housing - 1 chute - Mondial		5.20
A-17369	Reject shaft - 1 chute	76	1.50
A-17370	Reject shaft - 2 chutes	76	1.76
A-17371	Reject shaft - 3 chutes	76	1.92
B-17372	Assembly reject mechanism - 1 chute	76	4.60
B-17373	Assembly reject mechanism - 2 chutes	76	5.00
B-17374	Assembly reject mechanism - 3 chutes	76	5.50
B-17376	Coin return cover - 1 chute	78	2.72
B-17378	Wiper		1.76
A-17379	Switch mounting bracket06
A-17380	Printed insert, 2 x 100 Lire - 3 plays	73	.08
B-17382	Line cord - France 2 wire		2.20
B-17384	Disc		4.80
A-17385	Plastic target - 4 Star Flash	22	.36
C-17386	Disc		11.50
C-17387	Wiper		5.00
A-17397	Coil mounting bracket and stops	42	2.40
B-17399	Switch assembly with bracket, 2A, dip target		2.22
C-17408	Plastic shield set (specify game)		15.00
C-17418	Plastic shield set (specify game)		15.00
B-17419	Switch assembly with bracket - contact	23	1.36
B-17420	Switch assembly with bracket - contact		1.40
B-17421	Switch assembly with bracket - contact		1.40
B-17422	Switch assembly with bracket - contact		1.40
B-17423	Switch assembly with bracket - contact		1.32
B-17424	Switch assembly with bracket - contact	23	1.36

PRICE LIST

Arranged in Numerical Order

Part No.	Description	Page	Price
B-17425	Switch assembly with bracket — contact		1.40
B-17426	Switch assembly with bracket — contact		1.36
B-17427	Switch assembly with bracket — contact		1.40
B-17428	Switch assembly with bracket — contact		1.32
B-17429	Switch assembly with bracket — kicking rubber		1.62
B-17430	Switch assembly with bracket — kicking rubber	10	1.62
B-17431	Switch assembly with bracket — kicking rubber		1.62
B-17432	Switch assembly with bracket — kicking rubber	10	1.62
D-17440	Cashbox		6.00
D-17441	Cashbox cover		4.00
B-17446	Line cord — Japan		4.00
B-17481	Disc		4.60
B-17482	Transformer		72.00
A-17484	Gear and shaft		3.24
C-17492	Siamese post	21	.20
A-17493	Rubber ring	21	.12
A-17494	Swinging target mounting bracket	21	.06
A-17495	Swinging target mounting bracket	21	.08
A-17496	Swinging target blade24
B-17497	Switch assembly, 1C, swinging target	21	1.52
B-17505	Switch assembly, 1B, 3A, motor		3.22
C-17512	Plastic shield set (specify game)		14.50
B-17516	Switch assembly, 1A, 3B, motor		2.94
B-17543	Switch assembly, 1B, ball roll tilt	84	.80
A-17545	"AS" relay disc		4.30
A-17546	"AS" relay disc		4.30
A-17559	Swinging target, Eagle	21	1.50
A-17564	Coil		2.16
A-17565	Nylon bearing — flipper	14	.18
A-17596	Eyelet	26	.04
A-17650	Ball guide rail — wireform14
A-17657	Printed insert, 2 x 25¢ — 3 plays	73	.08
A-17607	Pop bumper coil, stop and bracket	2, 3	6.40
A-17755	Ball guide rail — wireform16
A-17911	Coin entrance plate, 1 play — 10 P.	72	1.04
A-17969	Swinging target, Flying Football	21	1.50