

Gottlieb SKY JUMP Gottlieb SKY DIVE

PLAYBOARD INFORMATION

RUBBER RINGS

| | | | |
|---|----------------|-------------|------|
| A | - A-10217 | 5/16" | (20) |
| B | - A-10219 | 1" | (3) |
| C | - A-10220 | 1-1/2" | (2) |
| D | - A-10221 | 2" | (1) |
| E | - A-10223 | 3" | (2) |
| F | - A-10225 | 4" | (1) |
| G | - A-13151 | 3/8"x1-1/2" | (2) |
| | Rebound rubber | | (1) |
| | Shooter tip | | (1) |

PARTS LIST


1. A-3290 Ball Gate.
2. A-9143 Rebound Rubber.
3. C-15047 Plastic Shield Set.
4. Red Pop Bumper A-13905 and A-15166 Cap in Red.
5. Blue Pop Bumper A-13905 and A-11426 Cap in Blue.
6. A-9393 White Plastic Apron. (2)
7. A-9394 White Plastic Apron. (2)
8. A-9396 White Plastic Apron. (2)
9. A-9397 White Plastic Apron. (1)
10. A-9398 White Plastic Apron. (1)
11. Red Drop Target Bank.
12. A-14396 Plastic Targets. (Target & Switch Assem. B-9591)
13. A-4246 Ball Guide Rail. (Wire Form) (1)
14. A-4832 Ball Guide Rail. (Wire Form) (4)
15. A-6612 Ball Guide Rail. (Wire Form) (2)
16. A-13798 Ball Snubber Rail. (Wire Form) (2)
17. A-14571 Ball Guide Rail. (Wire Form) (1)
18. A-14572 Ball Guide Rail. (Wire Form) (1)
19. B-15052 Ball Guide Flat Rail.
20. C-7393 Wood Rail. (Left Side)
21. C-9771 Wood Rail. (Center)
22. C-13977 Wood Rail. (Right Side)
23. C-13150 Flippers (White)
24. C-9767 Ball Shooter Gage.
25. D-13647 Card Holder.

C-11561 White Plastic Post
1" High. (44)

LIB. = LIBERAL.
CON. = CONSERVATIVE.

marco Specialties, Inc.
rubber
RINGkit
"Customized for your machine!"

www.marco-spec.com
1200 West 10th Ave.
Longmont, CO 80501
800-877-8888 Fax: 303-661-8888



PLAYBOARD INFORMATION

RUBBER RINGS

| | | |
|---|---------|------|
| A | A-10217 | (18) |
| B | A-10219 | (4) |
| C | A-10220 | (2) |
| D | A-10221 | (1) |
| E | A-10223 | (2) |
| F | A-10225 | (1) |
| G | A-13151 | (2) |

PARTS LIST

1. A-3290 Ball Gate.
2. A-9143 Rebound Rubber.
3. C-15047 Plastic Shield Set.
4. Red Pop Bumper A-13905 and A-15166 Cap in Red.
5. Blue Pop Bumper A-13905 and A-11426 Cap in Blue.
6. A-9393 White Plastic Apron.
7. A-9394 White Plastic Apron.
8. A-9396 White Plastic Apron.
9. A-9397 White Plastic Apron.
10. A-9398 White Plastic Apron.
11. A-15177 Red Drop Target Bank.
12. A-14396 Plastic Targets. (Target & Switch Assem. B-11371)
13. A-4246 Ball Guide Rail. (Wire Form)
14. A-4832 Ball Guide Rail. (Wire Form)
15. A-6612 Ball Guide Rail. (Wire Form)
16. A-13798 Ball Snubber Rail. (Wire Form)
17. A-14571 Ball Guide Rail. (Wire Form)
18. A-14572 Ball Guide Rail. (Wire Form)
19. B-15052 Ball Guide Flat Rail.
20. C-7393 Wood Rail. (Left Side)
21. C-9771 Wood Rail. (Center)
22. C-13977 Wood Rail. (Right Side)
23. C-13150 Flippers (White)
24. C-9767 Ball Shooter Gage.
25. D-13647 Card Holder.

C-11561 White Plastic Post
1" High. (44)